



Audio 20

Operating Instructions



Order no. 6515 7955 13 Part no. 205 584 70 03 Edition A-2016

Audio 20 Supplement



Mercedes-Benz

Symbols


In this Operator's Manual you will find the following symbols:


WARNING

Warning notes make you aware of dangers which could pose a threat to your health or life, or to the health and life of others.

Environmental note

Environmental notes provide you with information on environmentally aware actions or disposal.

 Notes on material damage alert you to dangers that could lead to damage to your vehicle.

 Practical tips or further information that could be helpful to you.

- ▶ This symbol indicates an instruction that must be followed.
- ▶ Several of these symbols in succession indicate an instruction with several steps.

(▷ This symbol tells you where you can find more information about a topic.

Dis- This text indicates a message on the multifunction/Audio 20 display.

Parts of the software in the vehicle are protected by copyright © 2005
The FreeType Project
<http://www.freetype.org>. All rights reserved.

Publication details

Internet

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following websites:

<http://www.mbusa.com> (USA only)

<http://www.mercedes-benz.ca> (Canada only)

Editorial office

You are welcome to forward any queries or suggestions you may have regarding this Operator's Manual to the technical documentation team at the following address:

Daimler AG, HPC: CAC, Customer Service,
70546 Stuttgart, Germany

©Daimler AG: Not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Daimler AG.

Vehicle manufacturer

Daimler AG
Mercedesstraße 137
70327 Stuttgart
Germany

Welcome to the world of Mercedes-Benz

First of all, familiarize yourself with your Audio 20. Read these operating instructions, particularly the safety and warning notes, before you drive off.

This will help you to obtain the maximum pleasure from your Audio 20 and avoid endangering yourself and others.

The equipment level and functions of your Audio 20 may differ depending on:

- model
- order
- country specification
- availability

Mercedes-Benz is constantly updating its vehicles to the state of the art.

Mercedes-Benz therefore reserves the right to introduce changes in the following areas:

- design
- equipment
- technical features

The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.

Please consult an authorized Mercedes-Benz Center should you have any questions.



The Operator's Manual is an integral part of the vehicle. You should always keep it in the vehicle and pass it on to the new owner if you sell the vehicle.

The technical documentation team at Daimler AG wishes you safe and pleasant motoring.

Mercedes-Benz USA, LLC

Mercedes-Benz Canada, Inc.

A Daimler Company



Index	4	Overview and operation	15
Introduction	11	System settings	29
		Vehicle functions	39
		Navigation	53
		Telephone	57
		Online and Internet functions	79
		Radio	97
		Media	109
		Sound	129

1, 2, 3 ...

360° camera

Displaying images	44
Settings	44
Switching on/off	44

911 emergency call	59
---------------------------------	----

A**Access data of the mobile phone network provider**

Deleting	84
Editing	84
Making entries	83
Selecting	82

Acoustic locking confirmation

Activating/deactivating (Audio 20)	41
--	----

Activating media mode

General notes	110
Switching on automatically	111

Adding bookmarks	93
-------------------------------	----

Address book

Receiving vCards	72
------------------------	----

Adjusting the volume

Audio 20	25
Media source	25
Traffic announcements	25

Ambient light

Settings (Audio 20)	40
---------------------------	----

Asterisk key

see Favorites button

Audio 20

Adjusting the display	30
Basic functions	25
Controller	18
Display	17
Switching on/off	25

Audio CD/DVD and MP3 mode

Bluetooth® audio mode	118
Connecting USB devices	114
Data media, file systems, formats ..	111
Media interface	124
Media search	116
Overview menu	113
SD memory card	113
Search menu	115

Sound settings	130
----------------------	-----

Audio CD/MP3 mode

Switching to	114
--------------------	-----

Automatic locking feature

Activating/deactivating (Audio 20)	42
--	----

Automatic mirror folding function

Activating/deactivating (Audio 20)	42
--	----

Automatic time

Switching on/off	31
------------------------	----

Automatic volume adjustment

General information	34
Switching on/off	34

B

Back button	18
--------------------------	----

Belt adjustment

Activating/deactivating (Audio 20)	41
--	----

Bluetooth®

Activating audio mode	122
Activating/deactivating	34
Audio device mode and searching for mobile phones	121
Basic display (audio mode)	122
Connecting another mobile phone	63
Connecting audio devices	118
De-authorizing (de-registering) a device	122
Device list	119
Displaying connection details	64
Displaying details	121
Entering the passcode	62
External authorization (audio device)	120
General information	33
Interface	58
Introduction	58
Reconnecting an audio device	121
Searching for a mobile phone	61
Selecting a playback option	124
Selecting a track	123
Starting and stopping playback	122

- Starting playback if the Bluetooth® audio device has been stopped 123
 - Telephony 60
 - Telephony notes 58
 - Burmester® surround sound system**
 - Balance/fader 132
 - Calling up the sound menu 131
 - Equalizer 131
 - Equipment 131
 - Surround sound 132
 - Buttons and controller** 18
- C**
- Call lists**
 - Displaying details 73
 - Opening and selecting an entry 73
 - Category list (music search)** 116
 - CD**
 - Inserting 113
 - Notes on discs 113
 - CD mode**
 - Playback options 114
 - Climate control**
 - Audio 20 46
 - Calling up the climate control bar (Audio 20) 46
 - Calling up the climate control menu (Audio 20) 47
 - Cooling with air dehumidification (Audio 20) 49
 - Ionization (Audio 20) 48
 - Overview 45
 - Perfume atomizer (Audio 20) 47
 - Pre-entry climate control (Audio 20) 48
 - Pre-entry climate control at departure time (Audio 20) 48
 - Pre-entry climate control using the key (Audio 20) 48
 - Setting the air distribution (Audio 20) 46
 - Setting the airflow (Audio 20) 46
 - Setting the climate mode (Audio 20) 47
 - Setting the temperature (Audio 20) 46
 - Switching on/off (Audio 20) 48
 - Switching the ionization on/off (Audio 20) 48
 - Switching the synchronizing function on/off (Audio 20) 49
 - Using the key (Audio 20) 48
 - Climate control bar**
 - Calling up 46
 - Contacts**
 - Importing 71
 - Controller** 18
 - Correct use** 11
- D**
- Date format, setting** 33
 - Day design, setting** 30
 - Delayed switch-off**
 - Settings (Audio 20) 43
 - Destination/route download**
 - Deleting a destination from the server 90
 - Displaying destinations in the vehicle 89
 - Displaying the vehicle identification number (VIN) 90
 - Placing a call at the destination 89
 - Procedure and general information 88
 - Sending destinations to the server 88
 - Using a destination for route guidance 89
 - Using destinations 89
 - Dialing a number (telephone)** 65
 - Display**
 - Notes about cleaning 17
 - Selecting the design 30
 - Switching on/off 31
 - Displaying the artist and track**
 - Radio 102
 - DYNAMIC SELECT**
 - Configuration via the DYNAMIC SELECT switch 50
 - Configuring individual drive program 49

- Setting options 50
- E**
- E-mail**
Using a phone number in the text 77
- EASY-ENTRY/EXIT feature**
Activating/deactivating (Audio 20) 41
- F**
- Factory setting (reset function) 37**
- Favorites**
Adding 27
Deleting 28
Displaying and calling up 27
Moving 28
Overview 27
Renaming 28
- Favorites (Internet) 95**
- Favorites button 34**
- G**
- GARMIN® MAP PILOT 54**
- Google™ Local Search**
Calling up Local Search 85
Calling up settings 87
Deleting search queries 88
Entering a search position and search term 86
Importing a destination/route 86
Popular Searches 87
Search history 87
Setting the search radius 88
Using as the destination 86
- H**
- Handwriting recognition**
Switching text reader function on/off 23
Touchpad 23
- I**
- Importing/exporting data 35**
- Internet**
Conditions for access 80
Creating favorites 95
Entering the URL 92
Favorites manager 95
Favorites menu 96
Menu functions 92
Options menu 93
Selecting/setting access data 81
Setting automatic disconnection of the Internet connection 84
Setting up an Internet connection ... 81
- L**
- Lighting**
Switching the locator lighting on/off 42
- Lights**
Ambient light settings (Audio 20) 40
- List of access data**
New provider 82
- List of mobile phone network providers**
With the selected provider 82
- Locator lighting**
Switching on/off (Audio 20) 42
- Locking confirmation**
see Acoustic locking confirmation
- M**
- Media Interface**
Basic display 124
Playback options 126
Search 125
Selecting a music file 125
Supported devices 125
Supported file formats 125
Switching to Media Interface 124
- Media mode**
Switching on 110
- Media search**
Category list 116
Current tracklist 117
General information 117
General notes 116
Keyword search 117
Music genres 117
Selecting by cover 117
Starting the media search 116

Memory card

see SD memory card

Mercedes-Benz Apps 90

Microphone, switching on/off 67

Mobile phone

Authorizing 62

Connecting (Bluetooth® inter-
face) 60

Connecting another mobile
phone 63

De-authorizing 64

Displaying Bluetooth® connection
details 64

Enabling for Internet access 81

MP3

Copyright 112

Stop and playback function 115

Multimedia system

see Display

N**Navigation**

Adjusting the volume of the navi-
gation announcements 25

Garmin® MAP PILOT 54

Overview 54

Switching to 55

Navigation announcements

Switching off 26

O**Online and Internet functions**

Calling up the device list 83

Destination/routes download 88

Enabling a mobile phone for Inter-
net access 81

Ending the connection 85

Establishing a connection 85

Further Mercedes-Benz Apps 91

Manually setting the access data
of the mobile phone network pro-
vider 82

Mercedes-Benz Mobile Website 90

Options menu 91

Resetting settings 91

Selecting the access data of the
mobile phone network provider 82

Setting automatic disconnection
of the Internet connection 84

Setting up an Internet connection ... 81

Web browser 92

P**Perfume atomizer**

Setting the perfume intensity
(Audio 20) 47

Phone book

Automatically importing contacts
from the mobile phone 70

Calling up 69

Changing the display and sorting
criteria for contacts 70

Deleting a contact 71

Deleting imported contacts 72

Displaying the details of an entry 70

Importing contacts 71

Saving a contact 71

Searching for a contact 69

Symbol overview 69

Phone call

Dialing 65

Picture viewer

Changing view 127

Displaying pictures 126

Exiting the picture viewer 127

General notes 126

Starting a slide show 127

PIN protection

Activating/deactivating 35

Q**Quick access for audio and tele-
phone**

Changing the station/music
track 25

Sending DTMF tones 25

R**Radio**

Activating/deactivating the sta-
tion presets display 101

- Deleting a station 100
 - Displaying information 102
 - Displaying station information 102
 - Displaying the artist and track 102
 - Overview 98
 - Setting the waveband 99
 - Sound settings (balance, bass, treble) 102
 - Station list 100
 - Storing stations 100
 - Switching on 98
 - Tagging music tracks (downloading/purchasing tracks from the iTunes Store®) 101
 - Radio station**
 - Storing 100
 - Rear view camera**
 - Displaying the image 44
 - Object detection 45
 - Switching object detection on/off 45
 - Switching on/off (Audio 20) 45
 - Receiving vCards** 72
 - Redialing (telephone)** 65
 - Resetting (factory settings)** 37
- S**
- Safety notes**
 - Audio CD and MP3 mode 111
 - Operating safety 11
 - Using the telephone 58
 - Satellite radio**
 - Displaying information 106
 - Overview 104
 - Registering 103
 - Switching to 103
 - SatRadio**
 - Channel list updates 107
 - Memory functions 105
 - Music and sports alerts 105
 - Notes 102
 - Selecting a category 104
 - Selecting a channel 104
 - Tagging music tracks 106
 - SD memory card**
 - Ejecting 114
 - Inserting 114
 - Inserting/removing 113
 - Selecting stations**
 - Radio 99
 - Sending DTMF tones** 67
 - Setting access data**
 - Online and Internet 82
 - Setting the language**
 - Audio 20 34
 - Setting the night design** 30
 - Setting the volume**
 - Telephone calls 26
 - Setting the waveband**
 - Radio 99
 - Settings**
 - Sound settings 130
 - Short message**
 - see Text messages (SMS)
 - Sound**
 - Switching on/off 26
 - Sound settings**
 - Balance/fader 130
 - Calling up the sound menu 130
 - Equalizer 130
 - Sound system**
 - see Burmester® surround sound system
 - Speed dial**
 - Deleting 74
 - Setting up 74
 - Storing stations**
 - Radio 100
 - Switching between summer time and standard time** 32
 - Switching on media mode**
 - Using the Media button 110
 - Via the device list 111
 - Via the main function bar 110
 - System settings**
 - Automatic volume adjustment 34
 - Bluetooth® 33
 - Date 31
 - Importing/exporting data 35
 - Language 34
 - Time 31
 - Time zone 31

T

Telephone

Accepting a call (Audio 20)	65
Adding a call	66
Adjusting the volume for calls	26
Authorizing a mobile phone (connecting)	62
Call lists	73
Call waiting	68
Calls with several participants	67
Conference calls	68
Connecting a mobile phone (general information)	60
De-authorizing (disconnecting) a mobile phone	64
Deleting a speed dial preset	74
Deleting messages	77
Displaying Bluetooth® connection details	64
Downloading messages manually	76
Ending an active call	68
Entering a number	65
Entering phone numbers	65
Establishing the connection from the mobile phone	63
Function restrictions	59
Functions available during a call	66
General notes	58
Incoming call during an existing call	68
Making a call	65
Message conditions	75
Message settings	75
Operating options	59
Phone book	69
Reading messages	76
Reception and transmission volume	64
Reconnecting a mobile phone automatically	63
Redialing	65
Rejecting a call (Audio 20)	65
Safety notes	58
Sending DTMF tones	67
Setting up a speed dial	74
Switching between calls (call waiting)	67

Switching between mobile phones	63
Switching the microphone on/off	67
Telephone menu overview	59
Text message conditions	75
Text message settings	75
Text messages (SMS)	75
Toggling	67
Using the telephone	65

Telephone number

Entering	65
----------------	----

Text messages (SMS)

Calling the sender	77
Calling up the settings menu	75
Configuring the text messages displayed	75
Deleting	77
Displaying details	76
Downloading manually	76
Inbox	76
Reading	76
Settings	75
Using a phone number in the text	77

Time

Setting	32
Setting summer/standard time	32
Setting the format	33
Setting the time	32
Setting the time zone	31
Setting the time/date format	33
Switching automatic time on/off	31

Touchpad

Calling up quick access for audio and telephone	21
Changing the input language for handwriting recognition	24
Changing the station/music track	25
Character suggestions	23
Deleting characters	24
Entering a space	23
Entering characters	23
Gesture control	21
Handwriting recognition	23
Operating the touchpad	21
Overview	20
Quick access for audio and telephone	25

Switching	20
Switching input line	24
Trunk lid opening height restriction	
Activating/deactivating (Audio 20)	43
U	
USB audio mode	
Selecting a track	115
USB devices	
Connecting to the Media Interface	114
V	
Vehicle settings	
Calling up	40
Volume, adjusting	
Navigation messages	25
W	
Web browser	
Entering a web address	92

Operating safety

Important safety notes

WARNING

If you operate integrated communication equipment in the vehicle when driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident.

Only operate the equipment when the traffic situation permits. If you are not sure that this is possible, park the vehicle paying attention to traffic conditions and operate the equipment when the vehicle is stationary.

Bear in mind that at a speed of only 30 mph (approximately 50 km/h) your vehicle covers a distance of 44 feet (approximately 14 m) per second.

WARNING

Modifications to electronic components, their software as well as wiring can impair their function and/or the function of other networked components. In particular, systems relevant to safety could also be affected. As a result, these may no longer function as intended and/or jeopardize the operating safety of the vehicle. There is an increased risk of an accident and injury.

Never tamper with the wiring as well as electronic components or their software. You should have all work to electrical and electronic equipment carried out at a qualified specialist workshop.

If you make any changes to the vehicle electronics, the general operating permit is rendered invalid.

This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65.

This equipment has very low levels of RF energy that is deemed to comply without maximum permissive exposure evaluation

(MPE). But it is desirable that it should be installed and operated with at least 8 inches (20 cm) and more between the radiator and a person's body (excluding extremities: hands, wrists, feet and legs.)

Correct use

WARNING

Modifications to electronic components, their software as well as wiring can impair their function and/or the function of other networked components. In particular, systems relevant to safety could also be affected. As a result, these may no longer function as intended and/or jeopardize the operating safety of the vehicle. There is an increased risk of an accident and injury.

Never tamper with the wiring as well as electronic components or their software. You should have all work to electrical and electronic equipment carried out at a qualified specialist workshop.

Always observe the following when using Audio 20:

- the safety notes in this manual
- traffic rules and regulations
- laws and safety standards pertaining to motor vehicles

Roof antenna functionality (telephone, satellite radio, GPS) can be affected by the use of roof carrier systems.

Attaching metalized retrofit film to the windshield may affect radio reception and have a negative impact on all other antennas (e.g. emergency antenna) in the vehicle interior.

Protection against theft: this device is equipped with technical provisions to protect it against theft. Further information on protection against theft can be obtained from an authorized Mercedes-Benz Center.

Declarations of conformity

Vehicle components which receive and/or transmit radio waves

i USA only: The wireless devices of this vehicle comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) These devices may not cause interference, and
- 2) These devices must accept any interference, including interference that may cause undesired operation of the device. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

i Canada only: The wireless devices of this vehicle comply with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1) These devices may not cause interference, and
- 2) These devices must accept any interference, including interference that may cause undesired operation of the device.

Qualified specialist workshop

Read the information on qualified specialist workshops in the vehicle Operator's Manual.

Function restrictions

For safety reasons, some functions are restricted or unavailable while the vehicle is in motion. You will notice this, for example, because you will not be able to select certain menu items.

Data stored in the vehicle

Data recording

This vehicle is capable of recording diagnostic information relating to vehicle operation, malfunctions, and user settings. This may include information about the performance or status of various systems, including but not limited to, engine, throttle, steering or brake systems, that is stored and can be read out with suitable devices, particularly when the vehicle is serviced. The data obtained is used to properly diagnose and service your vehicle or to further optimize and develop vehicle functions.

Audio 20/mbrace

If the vehicle is equipped with Audio 20 or mbrace, additional data about the vehicle's operation, the use of the vehicle in certain situations, and the location of the vehicle may be compiled through Audio 20 or the mbrace system.

For additional information please refer to the Audio 20 operating instructions and/or the mbrace Terms and Conditions.

Event data recorders

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record data that will assist in understanding how a vehicle's systems performed in certain crash or near crash-like situations, such as during air bag deployment or when hitting a road obstacle. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- how various systems in your vehicle are operating
- whether or not the driver and passenger seat belts are fastened

- how far (if at all) the driver is depressing the accelerator and/or brake pedal and
- how fast the vehicle is traveling

This data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data is recorded by your vehicle only if a non-trivial crash situation occurs; no data is recorded by the EDR under normal driving conditions and no personal data (e.g. name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, can combine the EDR data with the type of personal identification data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties that have the special equipment, such as law enforcement, can read the information by accessing the vehicle or the EDR.

EDR data may be used in civil and criminal matters as a tool in accident reconstruction, accident claims, and vehicle safety. Since the Crash Data Retrieval CDR tool that is used to extract data from the EDR is commercially available, Mercedes-Benz USA, LLC ("MBUSA") expressly disclaims any and all liability arising from the extraction of this information by unauthorized Mercedes-Benz personnel.

MBUSA will not share EDR data with others without the consent of the vehicle owners or, if the vehicle is leased, without the consent of the lessee. Exceptions to this representation include responses to subpoenas by law enforcement; by federal, state or local government; in connection with or arising out of litigation involving MBUSA or its subsidiaries and affiliates; or, as required by law.

Warning: The EDR is a component of the Supplemental Restraint System ("SRS") Module. Tampering with, altering, modifying or removing the EDR component may result in a malfunction of the SRS Module and other systems.

State laws or regulations regarding EDRs that conflict with federal regulation are pre-empted. This means that in the event of such conflict, the federal regulation governs. As of February 2013, 13 states have enacted laws relating to EDRs.

Information on copyright

General information

Information on licenses for free and Open Source software used in your vehicle and in the electronic components can be found on this website: <http://www.mercedes-benz.com/opensource>.

Audio 20 features

- i** These operating instructions describe all the standard and optional equipment of your Audio 20 system, as available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions.
- i** Read the information on qualified specialist workshops in the vehicle Operator's Manual.

Overview	16
Touchpad	20
Basic functions	25
Favorites	27



Overview

Components



- ① Audio 20 display
- ② Single CD drive
- ③ Touchpad (for Audio 20 with touchpad)
- ④ Controller

Audio 20 consists of:

- the display
 - The Audio 20 display has 800 x 480 pixels.
- the single DVD drive
- the buttons
- the controller
- the touchpad (for Audio 20 with touchpad)
- ports in the center console (2 x USB, SD card slot)

An iPod® is connected via USB cable.

For Audio 20 with touchpad: the controller and touchpad provide two options for entering characters and selecting functions.

Functions

- **HD FM radio and HD AM radio/satellite radio**
- **Media**
 - Media support: audio CD, MP3 CD, two connection options for USB or Media

Interface (e.g. iPod®), SD card, Bluetooth® audio

- Music search using all media

- **Sound system**

You can select from two sound systems:

- Standard sound system
- Burmester® surround sound system

• Navigation system

- Navigation using SD memory card
- Realistic 3D map with textured city models

• Communication

- Reading text messages
- Internet browser
- Mercedes-Benz Apps with Google Local Search™, Facebook, stock prices, news and much more
- Mercedes-Benz Mobile Website

• Vehicle functions

- Vehicle settings, such as ambient lighting, belt adjustment and tow-away alarm
- Rear view camera
- Climate control functions, such as climate mode, perfume atomizer and auxiliary heating
- DYNAMIC SELECT (individual drive program)

• Favorites button

Fast access to favorites functions using the favorites button on the controller or on the touchpad

Display

General notes

! Avoid any direct contact with the display surface. Pressure on the display surface may result in impairments to the display, which could be irreversible.

Wearing polarized sunglasses may impair your ability to read the display.

The display has an automatic temperature-controlled switch-off feature. The brightness is automatically reduced if the temperature is too high. The display may then temporarily switch off completely.

Overview



- ① Status bar with displays
- ② Cover view (if available)
- ③ Main display field
- ④ Climate control status display

The example shows media playback with Audio CD.

Cleaning instructions


! Do not touch the display. The display has a very sensitive high-gloss surface; there is a risk of scratching. If you have to clean the screen, however, use a mild cleaning agent and a soft, lint-free cloth.

The display must be switched off and have cooled down before you start cleaning. Clean the display screen, when necessary, with a commercially available microfiber cloth and cleaning agent for TFT and LCD displays. Do not apply pressure to the display surface when cleaning it, as this could cause irreversible damage to the display. Then, dry the surface with a dry microfiber cloth.

Avoid using alcoholic thinners, gasoline or abrasive cleaning agents. These could damage the display surface.

Buttons and controller


Overview





- ① Navigation button
- ② Radio button
- ③ Media button
- ④ Telephone button
- ⑤ Vehicle and system settings button
- ⑥ Back button
- ⑦ Favorites button
- ⑧ Adjusts the volume or mutes
- ⑨ Switches Audio 20 on or off
- ⑩ Controller

Example: with touchpad

Back button

You can use the  button to exit a menu or to call up the basic display of the current operating mode.






- ▶ **To exit the menu:** briefly press the  button.
Audio 20 changes to the next higher menu level in the current operating mode.
- ▶ **To call up the basic display:** press the  button for longer than two seconds.
Audio 20 changes to the basic display of the current operating mode.

Controller

The controller in the center console lets you:

- select menu items on the display
- enter characters
- select a destination on the map
- save entries

The controller can be:

- turned 
- slid left or right 
- slid forwards or back 
- slid diagonally 
- pressed briefly or pressed and held 

Favorites button

With the favorites button, you can select, add or edit favorites.

- ▶ Press the favorites button on the controller. The favorites are displayed.
- ▶ **To select a favorite:** turn and press the controller.

Other functions (▷ page 27).

Touchpad








For Audio 20 with the touchpad: alternatively, you can use the touchpad to select and enter information (▷ page 20).

Multifunction steering wheel



- ① Multifunction display
- ② Right control panel
- ③ Left control panel

Left control panel

	• Calls up the main menu
	Press briefly: <ul style="list-style-type: none"> • Scrolls in lists • Selects a menu or function • In the Radio/Media menu: opens the track or station list and selects a station or an audio track • In the Telephone menu: switches to the phone book and selects a name or a telephone number
	
	Press and hold: <ul style="list-style-type: none"> • Rapid scrolling in all lists • In the Radio/Media menu: selects a station or audio track using rapid scrolling • In the Telephone menu: starts rapid scrolling if the phone book is open
	
	<ul style="list-style-type: none"> • In all menus: confirms the selected entry in the list • In the Radio/Media menu: opens the list of available radio sources/media • In the Telephone menu: switches to the phone book and starts dialing the selected number
	Switches off the Garmin® MAP PILOT voice control system (see the manufacturer's operating instructions)

**Press briefly:**

- Back
- In the **Radio/Media** menu: deselects the track or station list or list of available radio sources/media
- Hides display messages
- Exits the telephone book/redial memory

**Press and hold:**

- Calls up the standard display in the **Trip** menu

Right control panel

- Rejects or ends a call
- Exits phone book/redial memory



- Makes or accepts a call
- Switches to the redial memory



- Adjusts the volume




- Mute



- Switches on the Garmin® MAP PILOT voice control system (see the manufacturer's operating instructions)

Touchpad**Touchpad overview**

- ❗ Do not use any sharp objects on the touchpad. This could damage the touchpad.



P82.89-0180-31

- ① Touch-sensitive surface
- ② Favorites button
- ③ To call up quick access for audio and telephone
- ④ Back button

Using the touchpad, you can:

- select menu items in the display (▷ page 21).
- enter characters (handwriting recognition) (▷ page 23).
- control the active audio source (▷ page 25).
- create, manage and call up favorites (▷ page 27).
- save entries


Further information on operating the touchpad (▷ page 21).

Switching the touchpad on/off

- ▶ Press the button. The vehicle menu is displayed.
- ▶ To select **System Settings**: slide turn and press the controller. A menu appears.
- ▶ To select **Activate Touchpad**: turn and press the controller. The touchpad is switched on or off .

Operating the touchpad

Selecting a menu item



- ▶ Use one finger to touch the touch-sensitive surface.
- ▶ Glide your finger up, down, to the left or right.
The selection in the display moves in accordance with the direction of movement.

You can navigate in lists or menus in this way.


Confirming a selection



Do not press your finger too hard on the touchpad. This could cause malfunctions.

- ▶ Use one finger to press the touch-sensitive surface until you reach the pressure point.
A menu, an option or an application is started.


Calling up quick access for audio and telephone



- ▶ Use two fingers to touch the lower part of the touch-sensitive surface.
- ▶ Glide your fingers up.
Quick access is displayed.


Further information on quick access for audio and telephone (▷ page 25).

Hiding the quick access for audio and telephone



- ▶ Use two fingers to touch the touch-sensitive surface.
- ▶ Glide your fingers down.
Quick access is hidden.

Operating the control for vehicle and sound settings




P82.89-0369-31

- ▶ Touch the touch-sensitive surface with two fingers, spaced slightly apart.
- ▶ Turn both fingers clockwise. The control setting is increased.

or


- ▶ Turn both fingers counter-clockwise. The control setting is decreased.

Moving the map



P82.89-0348-31


- ▶ Use one finger to press the touch-sensitive surface until you reach the pressure point. The crosshair is shown.



P82.89-0352-31

- ▶ Touch the touch-sensitive surface again with one finger.
- ▶ Glide your finger in any direction. The map is moved in the direction of movement.


Zooming in on the map



P82.89-0349-31

- ▶ Touch the touch-sensitive surface with two fingers, spaced slightly apart.
- ▶ Glide your fingers away from each other. The map scale is magnified.

Zooming out of the map




P82.89-0350-31

- ▶ Touch the touch-sensitive surface with two fingers, spaced far apart.
- ▶ Glide your fingers towards each other. The map scale is reduced.

Handwriting recognition

Handwriting recognition overview



- ① Active input line
- ② To enter a space (▷ page 23)
- ③ Illustration of the touch-sensitive surface
- ④ To delete characters (▷ page 24)

You can use handwriting recognition for text, numbers or characters in any input line.

If the character that you have entered can be interpreted in different ways, these options are displayed. More information on the character suggestions (▷ page 23).



You can additionally switch the handwriting recognition read-aloud function on and off.



- ① To exit the menu
 - ② To return to handwriting recognition
 - ③ To change the input line or the position of the cursor
 - ④ To change the input language
 - ⑤ To finish character entry
- ▶ **To display the menu:** press the touchpad.

Switching the text reader function of the handwriting recognition on/off

You can switch the text reader function of the handwriting recognition on or off.

- ▶ Press the  button.
The vehicle menu is displayed.
- ▶ To select **System Settings**: slide  turn and press the controller.
A menu appears.
- ▶ To select **Read Out Handwriting Recognition**: turn and press the controller.
The text reader function is switched on or off .

Entering characters

Prerequisite: an input line for text, numbers or characters has been selected.

- ▶ Use one finger to draw the desired character on the touch-sensitive surface.
The character recognized is entered in the input line. You can draw the next character on the touch-sensitive surface.

If the character can be interpreted in different ways, these options are displayed.

More information on the character suggestions (▷ page 23).

Character suggestions

- ▶ **To select a character suggestion:** turn the controller.
The selected character is entered instead of the automatically recognized character. Character entry can be continued.

Entering a space

Prerequisite: an input line for text, numbers or characters has been selected.


- ▶ Use your finger to touch the touch-sensitive surface and glide to the right.
A space is entered into the input line.

Deleting characters

Prerequisite: an input line for text, numbers or characters has been selected.

- ▶ Use your finger to touch the touch-sensitive surface and glide to the left. The character last entered is deleted.


Switching input line



P82.89-0800-31

- ▶ Press the touchpad. A symbol is shown.
- ▶ To select **[T/]**: glide your finger to the left or right and press.
- ▶ To select the desired input line, glide up or down and press. The selected input line is active and character entry can be continued.

Moving the cursor within the input line



P82.89-0800-31

- ▶ Press the touchpad. A symbol is shown.
- ▶ To select **[T/]**: glide your finger to the left or right and press.
- ▶ To move the cursor, glide to the left or right.

Changing the input language for handwriting recognition

Prerequisite: an input line for text, numbers or characters has been selected.

- ▶ Press the touchpad. A symbol is shown.
- ▶ To select **[🌐]**: glide your finger to the left or right and press. The list of available input languages appears.
- ▶ To select a language: glide up or down and press. To select a language: glide up or down and press. The input language for handwriting recognition has been changed.

Searching in lists

The phone book search is used as an example.

You determine the first letter of the contact you are looking for with the first character you enter.

- ▶ Draw the letter on the touchpad surface. The first contact with the selected first character is highlighted in the phone book. Further information on handwriting recognition on the touchpad (▷ page 23).
- ▶ Draw additional letters on the touchpad surface one after another.
- ▶ **To complete the search and return to the phone book:** press the touchpad.

Switching between the controller and the touchpad as input device

Prerequisite: an input line for text, numbers or characters has been selected.

- ▶ **To switch from character entry using the controller to handwriting recognition on the touchpad:** use one finger to press the touchpad. Handwriting recognition on the touchpad is active.

- ▶ **To switch from handwriting recognition on the touchpad to character entry using the controller:** press the controller. Character entry using the controller is active.

Quick access for audio and telephone

Changing the station/music track



Depending on the audio source that is currently activated, you can use this function to select the next station or music track.

- ▶ Call up quick access (▷ page 21). The current audio source is displayed.
- ▶ To select the previous or next station or the previous or next music track, swipe to the left or right. The selected station or music track is played.

Sending DTMF tones



The function is not supported by all mobile phones (see the manufacturer's operating instructions).

- ▶ Call up quick access during a call (▷ page 21).
- ▶ **To select the required characters:** glide your finger to the left or right and press. Every character selected will be transmitted immediately.

Basic functions

Switching Audio 20 on/off

- ▶ Press the **ON** button on the center console to the right of the controller. When you switch on Audio 20, a warning message will appear. Audio 20 calls up the previously selected menu. If you switch off Audio 20, playback of the current media source will also be switched off.

Adjusting the volume

Adjusting the volume for media sources

- ▶ Turn the thumbwheel to the right of the controller.
- or
- ▶ Press the **+** or **-** button on the multifunction steering wheel. The volume of the media source currently selected changes.

Adjusting the volume for traffic announcements and navigation announcements

During traffic or navigation announcements:

- ▶ Turn the thumbwheel to the right of the controller.
- or
- ▶ Press the **+** or **-** button on the multifunction steering wheel.



- i** You can set the volume for navigation announcements to be different from the volume of the respective media source.

Adjusting the volume for phone calls

You can adjust the volume for hands-free mode during a telephone call.

- ▶ Turn the thumbwheel to the right of the controller.

or

- ▶ Press the  or  button on the multifunction steering wheel.

- i** Volume control for the Garmin® MAP PILOT voice control system (see the manufacturer's operating instructions).


Switching the sound on or off

Media source sound

- ▶ Press the thumbwheel to the right of the controller.

or

- ▶ Press the  button on the multifunction steering wheel.

- i** If the audio output is switched off, the status line will show the  symbol. If you switch the media source or change the volume, the sound is automatically switched on.

- i** Even if the sound is switched off, you will still hear navigation system announcements.

Switching navigation announcements off and on again

If your vehicle is equipped with GARMIN® MAP PILOT, you can switch navigation announcements on and off.

- ▶ **To switch off navigation announcements:** press the thumbwheel to the right of the controller during the announcement. The **Spoken driving recommendations have been deactivated.** message appears.

- ▶ **To switch navigation announcements on again:** switch Audio 20 off and then on again (▷ page 25).

or

- ▶ If navigation is available via an SD card, start a new route calculation.

Basic menu displays



- ▶ Press the , , ,  or  button.




Navigation (if available): the main menu appears.

Radio: the basic menu of the last radio mode set appears.

Media: the basic display for the last media source set appears.

Communication: the basic menu of the last communication function set appears.

Vehicle functions: the basic display appears (example).

- ▶ **To show the menu:** slide    the controller.

The menu for the selected functions appears. Depending on the operation, the marking is shown in main function bar (top) or menu bar (bottom).

- ▶ **To select a menu item:** turn and press the controller.

If you have selected a menu item from the main function bar, switch to the last menu set for the selected function.

The menu bar features options within the currently set function.

Selecting the operating mode for a main function

You can select the available operating modes for the main functions, e.g. telephone

In the Telephone menu you can:


- switch to telephone mode
 - call up the digital operating instructions for the telephone
- ▶ Press the **TEL** button.
If telephone mode was the last mode selected, the telephone menu appears.
- ▶ **To call up the menu:** press the **TEL** button again.

or

- ▶ To select **Phone**↑⊙ slide and press the controller.
A menu appears. **Phone** is at the front.
- ▶ To select **Info on Phone**, for example: turn and press the controller.

Favorites

Overview of favorites



- ① To add a new favorite (▷ page 27)
- ② To rename a selected favorite (▷ page 28)
- ③ To move a selected favorite (▷ page 28)
- ④ To delete a selected favorite (▷ page 28)

- ▶ **To display the favorites overview:** press the favorites button on the controller.

- ▶ **To show the menu bar:** slide ⊙↓ the controller.

You can manage a total of 20 favorites.

To do so use the following functions:

- Displaying and selecting favorites (▷ page 27)
- Adding favorites (▷ page 27)
- Renaming favorites (▷ page 28)
- Moving favorites (▷ page 28)
- Deleting favorites (▷ page 28)

Displaying and selecting favorites

- ▶ **To display the favorites overview:** press the favorites button on the controller.

- ▶ **To call up favorites:** turn and press the controller.

Adding favorites

Adding predefined favorites

- ▶ Press the favorites button on the controller.
- ▶ To show the menu bar, slide ⊙↓ the controller.

- ▶ To select **Reassign**, turn and press the controller.

The categories for favorites are displayed.

- **Entertainment**
- **Tel**
- **Vehicle**
- **Climate Control**

- ▶ **To select a category:** turn the controller and press to confirm.

The available favorites are displayed.

- ▶ **To select a favorite:** turn and press the controller.

- ▶ **Adding a favorite at the desired position:** turn and press the controller.

If a favorite is stored over another favorite, the favorite underneath is deleted.

Adding your own favorites

You can store phone numbers from the phone book or radio station as favorites.

A phone number from the phone book is used as an example.

- ▶ Call up the phone book (▷ page 69).
- ▶ Search for the contact and display the phone number: (▷ page 69).
- ▶ **To add a telephone number as a favorite at the desired position:** press and hold the favorites button on the controller until the favorites are displayed.
- ▶ Turn and press the controller.
If a favorite is stored over another favorite, the favorite underneath is deleted.

Renaming favorites


- ▶ Press the favorites button on the controller.
The favorites are displayed.
- ▶ **To select the favorite to be renamed:** turn the controller.
- ▶ **To show the menu bar:** slide Ⓞ↓ the controller.
- ▶ To select **Rename:** turn and press the controller.
- ▶ Enter characters using the controller or the touchpad (▷ page 23).
- ▶ **To finish the entry:** select **OK**.
The favorite has been renamed.

- ▶ Press the favorites button on the controller.
The favorites are displayed.
- ▶ **To select the favorite to be moved:** turn the controller.
- ▶ **To show the menu bar:** slide Ⓞ↓ the controller.
- ▶ To select **Move:** turn and press the controller.
- ▶ **To store the favorite in the desired order:** turn and press the controller.
If a favorite is stored over another favorite, the favorite underneath is deleted.

Deleting favorites

- ▶ Press the favorites button on the controller.
The favorites are displayed.
- ▶ **To select the favorite to be deleted:** turn the controller.
- ▶ **To show the menu bar:** slide Ⓞ↓ the controller.
- ▶ To select **Delete**, turn and press the controller.
- ▶ To select **Yes**, turn and press the controller.
The favorite is deleted.
- ▶ If you select **No**, the process will be canceled.

Moving favorites



Audio 20 features	30
Important safety notes	30
Display settings	30
Time settings	31
Bluetooth® settings	33
Automatic volume adjustment	34
Setting the system language	34
Calling up and editing the Favorites function	34
Importing/exporting data	35
Reset function	37

Audio 20 features

i These operating instructions describe all the standard and optional equipment of your Audio 20 system, as available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions.

i Read the information on qualified specialist workshops in the vehicle Operator's Manual.

Important safety notes

WARNING

If you operate mobile communication equipment while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident. Only operate this equipment when the vehicle is stationary.

WARNING

SD memory cards are small parts. They can be swallowed and cause asphyxiation. This poses an increased risk of injury or even fatal injury.


Keep SD memory cards out of the reach of children. If an SD memory card is swallowed, seek immediate medical attention.



You must observe the legal requirements for the country in which you are currently driving when operating mobile communications equipment in the vehicle.

Display settings

Setting the brightness



The brightness detected by the display light sensor affects the setting options for this function.



- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **System Settings**: slide , turn and press the controller to confirm. A menu appears.
- ▶ To select **Display**: turn and press the controller. A menu appears.
- ▶ Select **Brightness**. A control appears.
- ▶ Select the desired brightness.



Display design

The display features optimized designs for daytime and night-time operation. You can set the design by manually selecting day or night design or opt for an automatic setting.

- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **System Settings**: slide , turn and press the controller to confirm. A menu appears.
- ▶ To select **Display**: turn and press the controller. A menu appears.
- ▶ Select **Day Mode**, **Night Mode** or **Auto**. The **•** dot indicates the current setting.

Design	Explanation
Day Mode	The display is set permanently to day design.
Night Mode	The display is set permanently to night design.
Automatic	In the Automatic setting, Audio 20 evaluates the readings from the light sensor and automatically switches the display design.

Switching the display on/off

- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **Display Off**: slide , turn and press the controller to confirm. The display goes out.
- ▶ **To switch the display on again**: press the controller.

Time settings

General information

You can manually set the time and date with Audio 20.



If your vehicle is equipped with GPS, Audio 20 can automatically set the time and date.

The following navigation system functions require the time, time zone and summer and standard time to be set correctly in order to work properly:

- route guidance on routes with time-dependent traffic guidance
- calculation of expected time of arrival

Switching automatic time on and off



The **Automatic Time Settings** function is used to activate or deactivate the automatic setting of the time and date. This function is activated when the vehicle leaves the factory. The **Automatic Time Settings** function is only available in vehicles with GPS reception.

- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **Time**: slide , turn and press the controller to confirm. A menu appears.
- ▶ To select **Automatic Time Settings**: press the controller.
- ▶ To switch the function on or off : press the controller.

Setting the time zone

To set the time zone, the **Automatic Time Settings** function must be activated.

The **Time Zone**: function is only available in vehicles with GPS reception.

- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **Time**: slide , turn and press the controller to confirm. A menu appears.
- ▶ To select **Time Zone**:: turn and press the controller. A list of countries appears. The ● dot indicates the current setting.
- ▶ **To select the country in which you are currently driving**: turn and press the controller. The country is accepted.

A time zone list may also be displayed, depending on the country selected.



- ▶ **To select the desired time zone:** turn and press the controller. The time zone is accepted.

A list of available options for setting summer time appears (▶ page 32).

Setting summer and standard time


You can use the **Daylight Saving Time** menu to set automatic summer time change-over or switch the summer time setting on or off. The changeover to summer time advances the time by one hour.

The **Daylight Saving Time** menu or the **Automatic** option is not available in all countries and is only available in vehicles with GPS reception.



- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **Time**: slide , turn and press the controller to confirm. A menu appears.
- ▶ To select **Daylight Saving Time**: turn and press the controller. A list of available options for setting summer time appears.
- ▶ To select **Automatic**, **On** or **Off**: turn and press the controller.


Setting	Function
Automatic	The summer and standard time are automatically changed over.
On	The clock is advanced one hour ahead of standard time.
Off	The standard time for the chosen time zone is selected.

Manual time setting



Vehicles with GPS reception: with manual time setting, you can set the time back or forward by up to several hours.

- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **Time**: slide , turn and press the controller to confirm. A menu appears.
- ▶ To select **Set Time Manually**: turn and press the controller. A menu with an analog clock appears.
- ▶ To set the hour: turn the controller.

- ▶ To highlight minutes: slide  the controller.
- ▶ To set minutes: turn and press the controller. The time is accepted.

The **Automatic Time Settings** function is deactivated .

If **Automatic** is set for the summer time changeover, a prompt will appear asking whether the automatic changeover should be maintained between summer and winter time.


- i** If **Automatic Time Settings** is reactivated, the previous settings for time zone and summer time changeover are restored.

Setting the time and date format

Use this function to set the time and date format for all displays in the vehicle.

- ▶ Press the  button.

or

- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **Time**: slide , turn and press the controller to confirm. A menu appears.
- ▶ To select **Format**: turn and press the controller.
- ▶ To select the desired date format: turn and press the controller. The • dot indicates the current setting.
- ▶ To select the desired time format: turn and press the controller. The • dot indicates the current setting.

Abbreviation	Meaning
YYYY/MM/DD	Year/Month/Day date format, year (all four digits)
YY/MM/DD	Year/Month/Day date format, year (two digits)

Abbreviation	Meaning
MM/DD/YYYY	Month/Day/Year date format, year (all four digits)
DD/MM/YYYY	Day/Month/Year date format, year (all four digits)
HH:MM (24 hrs)	Hours : Minutes (24 hour time format)
HH:MM (AM/PM)	Hours : Minutes (AM/PM time format)

Bluetooth® settings

General information about Bluetooth®



Bluetooth®-capable devices, e.g. mobile phones, need to comply with a certain profile in order to be connected to Audio 20. Every Bluetooth® device has its own specific Bluetooth® name.

Bluetooth® technology is a standard for short-range wireless data transmissions up to approximately 10 meters. You can use Bluetooth® to connect your mobile phone to Audio 20 to, for example:

- use the hands-free system
- establish an Internet connection
- listen to music using Bluetooth® Audio
- exchange vCards

Bluetooth® is a registered trademark of Bluetooth Special Interest Group (SIG) Inc.

Activating/deactivating Bluetooth®

- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **System Settings**: slide , turn and press the controller. A menu appears.
- ▶ To select **Activate Bluetooth**: turn and press the controller. This switches Bluetooth® on or off .


Automatic volume adjustment**General information**


With the **Automatic Volume Adjustment** function, the volumes of different audio sources are adjusted for each other, to compensate for relative differences in volume.

For example: changing from a relatively quiet to a relatively loud radio station. The volume for both stations sounds the same. Manual readjustment of the volume is not required.

The **Automatic Volume Adjustment** function is deactivated when the vehicle leaves the factory. Using this function, the dynamic range of the music is slightly reduced. To make the most of the audiophile sound quality, it is recommended to leave it off.



Switching the automatic volume adjustment on/off

- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.

- ▶ To select **System Settings**: slide , turn and press the controller. A menu appears.
- ▶ To select **Automatic Volume Adjustment**: turn and press the controller. Switch the **Automatic Volume Adjustment** function on or off .

Setting the system language

This function allows you to determine the language for the menu displays and the navigation messages. The selected language affects the characters available for entry.



- i** The navigation announcements are not available in all languages. If a language is not available, the navigation announcements will be in English.
- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **System Settings**: slide , turn and press the controller. A menu appears.
- ▶ To select **Language**: turn and press the controller. The list of languages appears. The ● dot indicates the current setting.
- ▶ Select the desired language. Audio 20 loads the selected language and stores the setting.

Calling up and editing the Favorites function

The Favorites function can, depending on the vehicle equipment, be called up as follows:

- via the **System Settings** menu
- via the Favorites button on the controller (▷ page 18)
- via the Favorites button on the touchpad (▷ page 20)

Calling up the Favorites function via the system menu:




- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **System Settings**: slide  and press the controller. A menu appears.
- ▶ To select **Favorite Functions**: press the controller. The favorites are displayed.
- ▶ To select the desired function, e.g. **Phone-book**: turn and press the controller.

Calling up the Favorites function via the controller or touchpad:

- ▶ Press the Favorites button on the controller or touchpad. The favorites are displayed.
- ▶ To select the desired function, e.g. **Phone-book**: turn and press the controller.

The Favorites function can be exited at any time.

To exit the Favorites function:

- ▶ Press the Favorites button again
- or
- ▶ Press the  button on the controller
- or
- ▶ Press the  button on the touchpad
- or
- ▶ To select  in the display: turn and press the controller.

Further information on favorites (> page 27).

Importing/exporting data

General notes


- ❗ Never remove the stick or card when writing data to the USB stick or the memory card. You may otherwise lose data.



Using this function, you can:

- transfer your personal Audio 20 data from one system/vehicle to another.
- make a backup copy (export data) and load it again (import data).
- protect your data from unwanted export by activating a pin prompt (presetting: deactivated).

You can either use an SD memory card or a USB storage device (e.g. a USB stick) as temporary storage.

Activating/deactivating PIN protection




- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **System Settings**: slide , turn and press the controller. A menu appears.
- ▶ To select **Data Import/Export**: turn and press the controller.
- ▶ Select **Activate PIN Protection**. Activate or deactivate PIN protection. When activating PIN protection, you will be prompted to enter a PIN.





- ▶ To enter the 4-digit PIN and select **ok** : turn and press the controller. You will be prompted to enter the PIN again.
- ▶ Enter the PIN again and select **ok** . The PIN prompt now protects your personal data from unwanted export.

i If you deactivate your PIN protection, you will first be prompted to enter your PIN. If you have forgotten your PIN, an authorized Mercedes-Benz Center can deactivate your PIN protection for you. Alternatively, you can deactivate PIN protection by resetting your personal Audio 20 data (▷ page 37).

Importing/exporting data



Audio 20 with GARMIN® MAP PILOT: if you want to import or export data using the SD memory card, you must first remove the SD memory card with the digital map (▷ page 114).

- ▶ Insert the SD memory card (▷ page 114).
- or
- ▶ Connect a USB device (e.g. a USB memory stick) (▷ page 114).
- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **System Settings**: slide  and press the controller. A menu appears.
- ▶ To select **Data Import/Export**: turn and press the controller.
- ▶ Select **Import Data** or **Export Data**.

i If you import data, the data on Audio 20 is overwritten. You will see a message to this effect. Audio 20 is restarted after the data import.



If PIN protection is activated, a PIN prompt appears when you select **Export Data**.

- ▶ To enter the PIN: turn the controller and press **ok** to confirm. PIN protection is deactivated.
- ▶ To select **Memory Card, USB 1** or **USB 2**: turn and press the controller. This function exports all the data to the selected disc. A window appears with the message that the data has been exported.

You can export bookmarks, system settings that you have made and radio station lists, for example.

Mercedes-Benz is not liable for any loss of data.

Reset function

You can reset Audio 20 to the factory settings. This includes the deletion of all of your Audio 20 personal data. These include, for example:


- Station presets
- Entries in the destination memory
- Authorized telephone

In addition, an activated PIN protection, which you have used to protect your data against unwanted export, will be deactivated. Resetting is recommended before selling or transferring ownership of your vehicle, for example.

Mercedes-Benz is not liable for any loss of data.

▶ Press the  button.

or

- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **System Settings**: slide , turn and press the controller to confirm. A menu appears.
- ▶ To select **Reset**: turn and press the controller. A prompt appears asking whether you wish to reset.
- ▶ Select **Yes** or **No**.
If you select **No** the process is canceled.
If you select **Yes** a prompt will appear again asking whether you really wish to reset.
- ▶ Select **Yes** or **No**.
If you select **Yes** a message will be shown. Audio 20 is reset to the factory settings and restarted.
If you select **No** the process is canceled.

Audio 20 features 40
Important safety notes 40
Vehicle settings 40
360° camera 44
Rear view camera 44
Climate control settings 45
DYNAMIC SELECT 49



Audio 20 features

- ▶ **i** These operating instructions describe all the standard and optional equipment of your Audio 20 system, as available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions.
- ▶ **i** Read the information on qualified specialist workshops in the vehicle Operator's Manual.

Important safety notes

WARNING


If you operate mobile communication equipment while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident. Only operate this equipment when the vehicle is stationary.

You must observe the legal requirements for the country in which you are currently driving when operating mobile communications equipment in the vehicle.


Vehicle settings

Calling up vehicle settings




- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ To select **Vehicle Settings**: press the controller. The **Vehicle Settings** menu is active.
- ▶ To select the desired vehicle setting: turn and press the controller. The main area with the setting element is active.

Selecting a different vehicle setting:

- ▶ To activate the menu for selecting the vehicle setting: slide  the controller.

Exiting the vehicle settings:

- ▶ To select : slide  and press the controller.

Ambient lighting

General notes

You can set the following for the ambient lighting:

- **Brightness**
This setting makes an additional change to the brightness of the ambient lighting.
- **Color**
This setting changes the color of the ambient lighting.

Setting the brightness

- ▶ Call up **Vehicle Settings** (▷ page 40).
- ▶ To select **Ambient Light Brightness**: turn and press the controller. The setting element is active. The brightness value is displayed.
- ▶ To change the brightness value: turn the controller.

You can find further information on the interior lighting in the vehicle Operator's Manual.

Setting the color

- ▶ Call up **Vehicle Settings** (▷ page 40).
- ▶ To select **Ambient Light Color**: turn and press the controller.
The setting element is active.
- ▶ To select a color: turn the controller.

You can find further information on the interior lighting in the vehicle Operator's Manual.

Switching the display lighting on/off

If the vehicle is not equipped with the "Ambient lighting" package, you can turn the display lighting on or off with this function.

- ▶ Call up **Vehicle Settings** (▷ page 40).
- ▶ To select **Ambient Light: Display**: turn and press the controller.
The function switches on or off, depending on the previous setting.

i The brightness can be adjusted using the controller on the rotary light switch.

You can find further information on the interior lighting in the vehicle Operator's Manual.

Setting the EASY-ENTRY/EXIT feature

This function makes getting in and out of your vehicle easier.

- ▶ Call up **Vehicle Settings** (▷ page 40).
- ▶ To select **Easy Entry/Exit**: turn and press the controller.
The setting element is active.
- ▶ To change the setting: press the controller.

You can find further information on the EASY-ENTRY/EXIT feature in the vehicle Operator's Manual.

Activating/deactivating the acoustic locking confirmation



You can also set an audible signal to confirm that the vehicle has been locked.

- ▶ Call up **Vehicle Settings** (▷ page 40).
- ▶ To select **Acoustic Lock Feedback**: turn and press the controller.
The function switches on or off, depending on the previous setting.

You can find further information on the locking feature in the vehicle Operator's Manual.

Activating/deactivating the seat-belt adjustment function



The **Belt Adjustment** function adjusts the driver's and front-passenger seat belt to the upper body of the occupants.

- ▶ Call up **Vehicle Settings** (▷ page 40).
- ▶ To select **Belt Adjustment**: turn and press the controller.
The function switches on or off, depending on the previous setting.

You can find further information on seat-belt adjustment in the vehicle Operator's Manual.

Activating/deactivating the automatic folding mirror function



When the **Automatic Mirror Folding** function is activated, the exterior mirrors fold in automatically as soon as you lock the vehicle from the outside. The exterior mirrors fold out automatically again as soon as you unlock the vehicle.


- ▶ Call up **Vehicle Settings** (▷ page 40).
- ▶ To select **Automatic Mirror Folding**: turn and press the controller. The function switches on or off, depending on the previous setting.

You can find further information on the automatic folding mirror function in the vehicle Operator's Manual.

Switching locator lighting on/off

If you switch on the **Locator Lighting** function, the exterior lighting is switched on for a short time when it is dark. The light switch must be set to **AUTO** (see the vehicle Operator's Manual).

The exterior lighting remains on for 40 seconds after the vehicle is unlocked. When you start the engine, the locator lighting is switched off and automatic headlamp mode is activated.



- ▶ Call up **Vehicle Settings** (▷ page 40).
- ▶ To select **Locator Lighting**: turn and press the controller.
- ▶ Press the controller. The function is switched on or off, depending on the previous status.

You can find further information on the locator lighting in the vehicle Operator's Manual.

Switching the automatic locking feature on/off



The vehicle is locked automatically when the ignition is switched on and the vehicle is traveling faster than walking pace.

- ▶ Call up **Vehicle Settings** (▷ page 40).
- ▶ To select **Automatic Locking**: turn and press the controller. The function switches on or off, depending on the previous setting.

You can find further information on the locking feature in the vehicle Operator's Manual.

Setting the delayed switch-off time

Interior lighting delayed switch-off



The interior lighting is activated for the duration of the delayed switch-off time when the SmartKey is removed from the ignition lock.

- ▶ Call up **Vehicle Settings** (> page 40).
- ▶ To select **Interior Lighting Delayed Switch-off**: turn and press the controller. The setting element is active.
- ▶ To change the delayed switch-off time: turn the controller.

You can find further information on the interior lighting in the vehicle Operator's Manual.

Exterior lighting delayed switch-off

If you switch on the **Exterior Lighting Delayed Switch-off** function, the exterior lighting is switched on for a short time after the engine is switched off. The light switch must be set to **AUTO** (see the vehicle Operator's Manual).

The exterior lighting remains on for 60 seconds after the engine is switched off. If you close all the doors and the tailgate, the exterior lighting switches off after the set time.



- ▶ Call up **Vehicle Settings** (> page 40).
- ▶ To select **Exterior Lighting Delayed Switch-off**: turn and press the controller. The setting element is active.
- ▶ To change the delayed switch-off time: turn the controller.

Activating/deactivating the trunk lid opening height restriction (Sedan)



Activating the **Trunk Opening-height Restriction** function allows you to avoid bumping the trunk lid on a low garage ceiling, for example. The setting via Audio 20 is only available in the C-Class Sedan.

- ▶ Call up **Vehicle Settings** (> page 40).
- ▶ To select **Trunk Opening-height Restriction**: turn and press the controller. The function switches on or off, depending on the previous setting.

360° camera

General notes

The 360° camera surveys the vehicle surroundings and assists you, for example when parking or at exits with reduced visibility.

The 360° camera is only an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering and parking. Make sure that no persons or animals are in the maneuvering range.

Further information on the 360° camera can be found in the vehicle Operator's Manual.

Displaying the 360° camera image

The 360° camera image can be displayed if:

- your vehicle is equipped with a 360° camera
- the **360° Camera** function is switched on; see the vehicle Operator's Manual.

▶ Press the  button.

or

▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.

▶ Select **360° Camera**.

The 360° camera image appears in split-screen mode.

You will see the previous view on the display if, when the function is switched on:

- you turn the SmartKey to position **1** in the ignition lock
- you select transmission position **P**
- when you are driving at moderate speeds

Switching the display off manually

▶ To select : slide  and press the controller.

Switching the display on automatically

▶ You can automatically switch the 360 camera display using reverse gear (> page 44).

For more information on the 360° camera, see the vehicle Operator's Manual.

Switching the 360° camera automatic mode on/off

This function activates the 360° camera when reverse gear is engaged.

▶ Press the  button.

or

▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.

▶ **To switch to the menu bar:** slide  the controller.

▶ To select **System Settings**: turn and press the controller.

▶ To select **360° Camera**: turn and press the controller. The **360° Camera** menu appears.

▶ Select **Activation by R gear**.

The function is switched on or off , depending on the previous status.

Opening the camera cover for cleaning

▶ To select **Open Camera Cover** in the 360° camera menu: turn the controller and press to confirm.

The **Please Wait...** message appears for approximately three seconds.

The camera cover opens.

The camera cover closes automatically if:

- the ignition is switched off
- the vehicle exceeds a moderate speed

Rear view camera

General notes



The rear view camera covers the immediate surroundings of the vehicle and assists you when parking.

The rear view camera is only an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering and parking. When maneuvering or parking, make sure that there are no persons, animals or objects in the area in which you are maneuvering.

You can find further information about the rear view camera in the vehicle Operator's Manual.

Switching the rear view camera automatic mode on/off

This function activates the rear view camera when reverse gear is engaged.

- ▶ Press the  button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ Slide  the controller.
- ▶ To select **System Settings**: turn and press the controller.
- ▶ Select **Rear View Camera**. The **Rear View Camera** menu appears.
- ▶ Select **Activation by R gear**. The function is switched on or off , depending on the previous status. When you start the vehicle and engage reverse gear, the camera cover opens automatically if the function is activated. The area behind the vehicle is shown with guide lines in the display (see the vehicle Operator's Manual).

For further information on the rear view camera, see the vehicle Operator's Manual.

Object detection

The rear view camera can detect moving and stationary objects. If, for example, a pedestrian or another vehicle is detected, these objects are marked with bars. The system is able to detect and mark stationary objects

when your vehicle is moving. Moving objects will always be detected and marked.

Switching object detection on/off

- ▶ To select **Object Detection** in the rear view camera menu: turn and press the controller. The function is switched on or off , depending on the previous status.

Opening the camera cover for cleaning

- ▶ To select **Open Camera Cover** in the rear view camera menu: turn and press the controller. The **Please Wait...** message appears for approximately three seconds. The camera cover opens.

The camera cover closes automatically if:

- the ignition is switched off
- the vehicle pulls away

Climate control settings

Overview


You can adjust the climate control settings using the climate control bar (▶ page 46) or the climate control menu (▶ page 47).

You can set the most important climate control functions, such as temperature (▶ page 46), airflow (▶ page 46) and air distribution (▶ page 46) using the climate control bar. The climate control bar is visible in most displays.

You can find all available climate control functions in the climate control menu. You can use the climate control bar (▶ page 46) to switch to the climate control menu.

Settings in the climate control bar

Overview



- ① Adjusts temperature and air distribution and displays the current setting
- ② Calls up the climate control menu and displays the current cooling setting
- ③ Adjusts air distribution and temperature and displays the current setting

Calling up the climate control bar

- ▶ Press the button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ Slide the controller repeatedly until the climate control bar is activated.

Setting the temperature



- ▶ Call up the climate control bar (▷ page 46).
- ▶ To select the current temperature on the left or right: turn and press the controller. The temperature setting scale appears.

- ▶ To change the setting: turn the controller.
- ▶ To close the temperature setting scale: press the controller.

i You can also use the climate control menu to set the temperature (▷ page 47).


Setting the air distribution



- ▶ Call up the climate control bar (▷ page 46).
- ▶ To select the current air distribution display, e.g. : turn and press the controller. The air distribution setting scale appears.
- ▶ To change the setting: turn the controller.
- ▶ To close the temperature setting scale: press the controller.

i You can also use the climate control menu (▷ page 48) to set the air distribution.


Setting the airflow



- ▶ Call up the climate control bar (▷ page 46).
- ▶ To select : turn and press the controller. The airflow setting scale appears.

- ▶ To change the setting: turn the controller.
 - ▶ To close the temperature setting scale: press the controller.
- i** You can also use the climate control menu (▷ page 47) to set the airflow.

Calling up the climate control menu



- ▶ Press the button.
- or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
 - ▶ Slide the controller repeatedly until the climate control bar is activated.
 - ▶ To select from climate control bar : turn and press the controller. The menu for selecting climate control functions is activated.
 - ▶ To select the desired climate control function: turn and press the controller. The selected climate control function appears.

Settings in the climate menu

Adjusting the climate mode settings



By setting the climate mode you determine the type of airflow. The setting is active when the air-conditioning system is set to **AUTO**, see the vehicle Operator's Manual.

- ▶ Call up the climate control menu (▷ page 48).
- ▶ To select **Climate Mode**: turn and press the controller.
- ▶ To change the setting: turn the controller.

Exiting a menu:

- ▶ Press the button.

The current airflow setting is shown in the climate control bar: **DIFFUSE**, **MEDIUM** or **FOCUS** (▷ page 46).


Starting/stopping the perfume atomizer




The perfume atomizer makes it possible to scent the air in individual compartments in the vehicle interior. Further information (see the vehicle Operator's Manual).

- ▶ Call up the climate control menu (▷ page 48).
- ▶ To select **Air Freshener**: turn and press the controller. The setting element is active.
- ▶ To start/stop the perfume atomizer: press the controller.
- ▶ To set the intensity: turn the controller when the atomizer is switched on.

Exiting a menu:

- ▶ Press the  button.


Switching the ionization on/off



The ionization has a cleansing effect on the air in the vehicle interior. Further information (see the vehicle Operator's Manual).

- ▶ Call up the climate control menu (▷ page 48).
- ▶ To select **Ionization**: turn and press the controller. The setting element is active.
- ▶ To switch the ionization on/off: press the controller.

Exiting a menu:

- ▶ Press the  button.

Pre-entry climate control via SmartKey


This function is available for hybrid and PLUG-IN HYBRID vehicles.

Hybrid: before getting in, the driver's seat area can be briefly warmed or ventilated in advance with the air from the air vents being pre-cooled.

PLUG-IN HYBRID: before getting in, the driver's seat area or the whole interior can be briefly warmed or ventilated in advance with the air from the air vents being pre-cooled.

- ▶ Call up the climate control menu (▷ page 47).
- ▶ **To select Pre-entry Climate Control via Key:** turn and press the controller.
- ▶ **To switch on or off:** turn and press the controller.

Exiting a menu:


- ▶ Press the  button.

Further information on pre-entry climate control; see the vehicle Operator's Manual.

Pre-entry climate control at time of departure

This function is available for PLUG-IN HYBRID vehicles.


You can climatize the driver's seat and the vehicle interior in time for the set departure time.

- ▶ Call up the climate control menu (▷ page 47).
- ▶ **To select Pre-entry Climate Ctrl. at Departure Time:** turn and press the controller. A rotary menu appears.
- ▶ **To select the desired setting:** turn the controller. The menu symbol, text and image show the selected setting.
- ▶ **Exiting a menu:** Press the  button.

Settings in the bottom bar of the climate control menu

Switching climate control on/off

This setting is made in the bottom bar of the climate control menu.



- ▶ Call up the climate control menu (▷ page 48).
- ▶ Slide the controller repeatedly until the bottom bar is activated.
- ▶ To select **Climate Ctrl On**: turn and press the controller.

The climate control is switched on or off depending on the settings.

If the climate control is switched off:

- the climate control setting functions are deactivated.
- the blower is switched off.
- the air recirculation flaps are closed.

Switching cooling with air dehumidification on/off

This setting is made in the bottom bar of the climate control menu.

- ▶ Call up the climate control menu (▷ page 48).
- ▶ Slide the controller repeatedly until the bottom bar is activated.
- ▶ To select **A/C**: turn and press the controller.
- ▶ Switch cooling with air dehumidification on or off .

- i** Deactivating the cooling with air dehumidification function reduces fuel consumption.

Synchronizing the climate control settings

Use **Sync** (synchronization) to select the climate control setting for all zones together or separately .

This setting is made in the bottom bar of the climate control menu.

- ▶ Call up the climate control menu (▷ page 48).
- ▶ Slide the controller repeatedly until the bottom bar is activated.
- ▶ To select **Sync**: turn and press the controller.
- ▶ Switch the synchronization function on or off .

For further information on synchronizing climate control settings (see the vehicle Operator's Manual).

DYNAMIC SELECT

General notes

This menu is available for vehicles with an automatic transmission. Press **DYNAMIC SELECT** to configure the following settings for the **Individual** drive program:

- Drive system
- Suspension
- Steering
- Climate control
- ECO start/stop function

You can also display current vehicle and engine data as well as the selected drive program.

- i** In a few countries, the ECO start/stop function is deactivated at the factory due to the available fuel grade. In this case, the ECO start/stop function is not available regardless of the display in the Audio 20 display.

The ECO Assist setting is available on PLUG-IN HYBRID vehicles.

In Mercedes AMG C63 vehicles, you can configure the following settings with **DYNAMIC SELECT** for the **Individual** drive program:

- Drive system
- Suspension
- Transmission
- Sports exhaust system
- Electronic Stability Program ESP®

There may be fewer settings depending on your vehicle's equipment.

For further information on the **Individual** drive program, see the vehicle Operator's Manual.


Configuration via the DYNAMIC SELECT switch

- i** There may be fewer settings depending on your vehicle's equipment.
- ▶ Use the DYNAMIC SELECT switch to select the **Individual** drive program; see the vehicle Operator's Manual. A window appears after a short while.
- ▶ **To confirm Adjust:** press the controller. The menu for setting the **Individual** drive program appears.
- ▶ **To select Drive, Suspension, Steering, Climate Control or Eco Start/Stop Function:** turn and press the controller.
- ▶ Select individual settings.

In Mercedes-AMG C63 vehicles, you can only configure the settings of the drive system, suspension, transmission, sports exhaust system and Electronic Stability Program ESP®.

Calling up vehicle data

- i** There may be fewer displays depending on your vehicle's equipment.

- ▶ Press the  button.
or
- ▶ Press **Vehicle** in the main function bar. The vehicle menu is displayed.
- ▶ **To select DYNAMIC SELECT:** turn and press the controller.
The **Vehicle Data** and **Engine Data** menus appear.
- ▶ **To select the desired time zone:** turn and press the controller.

Setting options

You can choose from the following settings for the drive:

C	Comfort
S	Sport
S+	Sport +
M	Manual
E	Eco

You can make the following settings for the suspension:

C	Comfort
S	Sport
S+	Sport +

You can make the following settings for the steering:

C	Comfort
S	Sport

You can choose from the following settings for climate control:

E	Eco
C	Comfort

You can choose from the following settings for the ECO start/stop function:

ON	Switches the ECO start/stop function on
Unlit	Switches the ECO start/stop function off

You can make the following settings for ECO Assist (PLUG-IN HYBRID vehicles):

ON	Switches ECO Assist on
Unlit	Switches ECO Assist off

Settings options for Mercedes-AMG C63 vehicles

You can choose from the following settings for the drive:

R	Race
C	Comfort
S	Sport
S+	Sport +

You can make the following settings for the suspension:

C	Comfort
S	Sport
S+	Sport +

You can choose from the following settings for the transmission:

D	Automatic
M	manually

You can make the following settings for the sports exhaust system:

C	Comfort
S	Sport
S+	Sport +

You can choose from the following settings for the Electronic Stability Program ESP®:

S	Sport
ON	Activates the Electronic Stability Program ESP®

You can find further information on the individual drive program in the vehicle Operator's Manual.

Audio 20 features 54
GARMIN® MAP PILOT navigation
module 54



Audio 20 features

- i** These operating instructions describe all the standard and optional equipment of your Audio 20 system, as available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions.
- i** Read the information on qualified specialist workshops in the vehicle Operator's Manual.

GARMIN® MAP PILOT navigation module

Important safety notes

WARNING

If you operate information systems and communication equipment integrated in the vehicle while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident. Only operate the equipment when the traffic situation permits. If you are not sure that this is possible, park the vehicle paying attention to traffic conditions and operate the equipment when the vehicle is stationary.

When using GARMIN® MAP PILOT, please observe the legal requirements of the country in which you are currently driving.

Always observe the traffic regulations when driving. Road and traffic rules and regulations always have priority over GARMIN® MAP PILOT driving recommendations.

WARNING

SD memory cards are small parts. They can be swallowed and cause asphyxiation. This poses an increased risk of injury or even fatal injury.

Keep SD memory cards out of the reach of children. If an SD memory card is swallowed, seek immediate medical attention.

General notes

The SD card box contains a quick guide to GARMIN® MAP PILOT. The GARMIN® MAP PILOT operating instructions are stored on the SD memory card as a PDF file.

GARMIN® MAP PILOT can be operated using the controller or the touchpad.

SD memory card and updates

- ▶ **To insert the SD memory card:** insert the SD memory card into the multimedia connector unit until it engages. The side with the contacts must face downwards and point towards the slot.

- i** Ensure that the write protection on the SD memory card is deactivated. To do this, the switch on the side must be pushed in the direction of the contacts and not the LOCK position.

- ▶ Follow the steps as instructed (observe the manufacturer's operating instructions).

You can obtain digital map and software updates from an authorized Mercedes-Benz Center.

For some countries, digital map and software updates are available in the form of a download or an SD memory card. To access them, visit the <http://shop.mercedes-benz.com> website and follow the instructions in the section "Garmin® MAP PILOT".

Further information; see the manufacturer's operating instructions.

Switching to navigation mode

- ▶ Press the **NAVI** button.
The navigation main menu appears. Further information; see the manufacturer's operating instructions.

Adjusting the volume

During a navigation announcement:

- ▶ Turn the thumbwheel to the right of the controller.
- or
- ▶ Press the **+** or **-** button on the multifunction steering wheel.
- i** You can set the volume for navigation announcements to be different from the volume of the respective media source.

Audio 20 features	58
Important safety notes	58
General notes	58
Telephone menu	59
Connecting/disconnecting a mobile phone	60
Reception and transmission vol- ume	64
Using the telephone	65
Phone book	69
Call lists	73
Speed dial lists	74
Messages (text messages and e- mails)	75

Audio 20 features

- i** These operating instructions describe all the standard and optional equipment of your Audio 20 system, as available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions.
- i** Read the information on qualified specialist workshops in the vehicle Operator's Manual.

Important safety notes

WARNING

If you operate mobile communication equipment while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident. Only operate this equipment when the vehicle is stationary.

If you make a call on your mobile phone while driving, always use hands-free mode. Only use the mobile phone when road, weather and traffic conditions permit. Some jurisdictions prohibit the driver from using a mobile phone while driving a vehicle.

Bear in mind that at a speed of 30 mph (approximately 50 km/h), the vehicle covers a distance of 44 feet (approximately 14 m) per second.

Excessive levels of electromagnetic radiation may cause damage to your health and the health of others.

There is scientific discussion surrounding the possible health risks posed by electromagnetic fields. You can reduce this risk by using an exterior antenna.

Therefore, connect your mobile communications equipment to the vehicle's exterior antenna wherever possible.

General notes

Telephony

A Bluetooth® interface is available for telephony.

If your mobile phone supports the PBAP Bluetooth® profile (**Phone Book Access Profile**), the contacts are automatically displayed in Audio 20.

You can use the message function if your mobile phone supports the MAP Bluetooth® profile (**Message Access Profile**).

With a suitable mobile phone, you can use the hands-free system and receive vCards via the Bluetooth® interface.

You can obtain more information about suitable mobile phones on the Internet at www.mercedes-benz-mobile.com.

Or call the Mercedes-Benz Customer Assistance center at 1-800-FOR-MERcedes(1-800-367-6372) for the USA or at 1-800-387-0100 for Canada.

HD Voice®

Audio 20 supports telephone calls in HD Voice®. The voice quality can be improved with this procedure.

Requirements for HD Voice®:

- Your mobile phone and mobile phone network provider support HD Voice®.
- The mobile phone and mobile phone network provider of the person you are calling support HD Voice®.

Depending on the quality of the connection, the voice quality may fluctuate.



Call disconnection while the vehicle is in motion

A call may be disconnected if:

- there is insufficient network coverage in certain areas.
- you move from one transmitter/receiver area (cell) into another and no channels are free.
- you use a SIM card that is not compatible with the network available.

Operating options

You can operate the telephone by:

- using the controller by turning, pressing, sliding ←⊙→ or ↑⊙↓
- using the touchpad (▷ page 21)
- using the  or  button on the multifunction steering wheel

All descriptions and illustrations in this section refer to Audio 20, unless stated otherwise.

Function restrictions

You may have to wait before using telephony via Audio 20 in the following situations:

- when the mobile phone is switched off
- if Bluetooth® is switched off on the mobile phone
- if the mobile phone has not logged on to a mobile phone network
- if the Bluetooth® function is switched off in Audio 20

The telephone automatically tries to log on to a network. If no network is available, you may not be able to make a "911" emergency call. If you attempt to make an outgoing call, the **No Service** message will appear for a short while.


"911" emergency call

The following requirements must be fulfilled for a **911** emergency call:

- a valid and operational SIM card is inserted in the mobile phone
- the mobile phone is switched on
- the PIN has been entered in the mobile phone
- a mobile phone network is available
- the mobile phone is connected to Audio 20 via Bluetooth®



If you cannot make an emergency call, you must arrange rescue measures yourself.

Making an emergency call:

- ▶ Enter the telephone number (▷ page 65).
- ▶ Press . The telephone makes the connection.
- ▶ Wait until the emergency call center answers and describe the emergency situation.

Telephone menu





- ① Mobile phone network provider
- ② Signal strength of the mobile phone network
- ③ Receiver icon  or 
- ④ Bluetooth® device name of the currently connected mobile phone
- ⑤ Telephone menu character bar
- ⑥ To display the phone book

Symbols ① to ④ are not shown until after a mobile phone has been connected to Audio

20. The symbols depend on your mobile phone and your mobile phone network provider. Further information on connecting a mobile phone (▷ page 60).

Symbol ② shows the current signal strength of the mobile phone network. If all bars are filled, you have optimum reception.


If the bars are not filled, you have very poor reception or no reception at all.


i Receiver icon shows whether a call is active/being connected  or not .


Calling up the telephone menu

▶ Press .

Showing the menu bar

▶ Slide  the controller.

If the mobile phone connected supports the MAP Bluetooth® profile (**M**essage **A**ccess **P**rofile), the  menu item is available. Further information on text messages (▷ page 75).

If you have an unread text message, the  mail symbol is displayed at the top in the status bar. The symbol disappears once you have read the text message.

Connecting/disconnecting a mobile phone

Prerequisites

For telephony via the Bluetooth® interface, you require a Bluetooth®-capable mobile phone. The mobile phone must support Hands-Free Profile 1.0 or above.

On Audio 20

▶ Activate Bluetooth® (▷ page 34).

On the mobile phone

▶ Switch on the mobile phone and enter the PIN when prompted to do so (see the manufacturer's operating instructions).

▶ Activate Bluetooth® and, if necessary, Bluetooth® visibility for other devices (see the manufacturer's operating instructions).

This visibility is for restricted periods of time on some mobile phones (see the manufacturer's operating instructions).

▶ Set the Bluetooth® device name for the mobile phone if necessary.

The Bluetooth® device names for all of one manufacturer's products might be identical. To make it possible to clearly identify your mobile phone, change the device name (see the manufacturer's operating instructions). The name can be freely selected.

If the mobile phone supports the PBAP (**P**hone **B**ook **A**ccess **P**rofile) and MAP (**M**essage **A**ccess **P**rofile) Bluetooth® profiles, the following information will be transmitted after you connect:

- Phone book
- Call lists
- Messages

Further information on allowing or suppressing the automatic download of the phone book (▷ page 70).

The battery of the mobile phone should always be kept sufficiently charged in order to prevent malfunctions.

i Not all mobile phones available on the market are equally suitable. You can obtain more detailed information about suitable mobile phones and about the connection between the mobile phone and Audio 20 on the Internet at **www.mercedes-benz-mobile.com**.

You can also obtain more information by calling.

In the USA, you can get in touch with the Mercedes-Benz Customer Assistance Center on 1-800-FOR-MERCEdes (1-800-367-6372).

In Canada, you can get in touch with the Customer Relations Center on 1-800-387-0100.

i Some displays (e.g. the signal strength) depend on the supported version of the Hands-Free Profile.

Procedure and general information

Searching for and authorizing (connecting) a mobile phone

Before using your mobile phone with Audio 20 for the first time, you will need to search for it (▷ page 61) and then authorize it (▷ page 62). Depending on the mobile phone, authorization either takes place by means of Secure Simple Pairing or by entering a passkey. Audio 20 automatically enables the procedure suited to your mobile phone. You can recognize Secure Simple Pairing by a code which is displayed in Audio 20 and on the mobile phone. You can recognize the passkey system by the fact that you have to enter a code on the mobile phone and in Audio 20. The mobile phone is always connected automatically after authorization.

If Audio 20 is unable to detect your mobile phone, this may be due to your mobile phone security settings. You can also start the search procedure and authorization on the mobile phone (▷ page 63).

Device-specific information on authorizing and connecting Bluetooth®-capable mobile phones can be found on the Internet at <http://www.mercedes-benz.com/connect>.


You can authorize up to 15 mobile phones. Only one mobile phone can be connected to Audio 20 at any one time.



De-authorizing (disconnecting) a mobile phone

The connection is terminated automatically if you leave the receiver range of Audio 20 or deactivate Bluetooth® on your mobile phone.


If you no longer want the Bluetooth® connection to be established automatically, the mobile phone must be de-authorized (disconnected) (▷ page 64).

Searching for a mobile phone



- ▶ To call up the telephone menu: press the  button.
- ▶ To switch to the menu bar in the telephone menu: slide  the controller.
- ▶ To select **Connect Device**: turn and press the controller.
The device list is displayed.
- ▶ To select **Search for Phones**: turn and press the controller.
A message is displayed that Bluetooth® must be activated on the mobile phone and must be made visible to other devices.
- ▶ To select **Start Search**: press the controller.
The available mobile phones are displayed in the device list.



The duration of the search depends on the number of Bluetooth® telephones within range and their characteristics.

If a new phone is found, it appears in the device list with the  symbol. You can now authorize (connect) the mobile phone found (▷ page 62).

If the maximum number of authorized devices in the device list is reached, you will be requested to de-authorize a mobile phone (▷ page 64).

When you call up the device list again, de-authorized devices will be removed from the list. To update the device list, start the search again.

Symbols in the device list

Symbol	Explanation
	New mobile phone found, not yet authorized.
	Mobile phone is authorized, but is not connected.
•	Mobile phone is authorized and connected.

Authorizing a mobile phone (connecting)

Authorization via Secure Simple Pairing

If Audio 20 has found your mobile phone, you can authorize (connect) it.

- ▶ To select a mobile phone from the device list: turn the controller and press to confirm.

A code is displayed in Audio 20 and on the mobile phone.

The code is the same

- ▶ **Audio 20:** select **Yes**.
- ▶ **Mobile phone:** confirm the code. Depending on the mobile phone used, you may have to confirm the connection to Audio 20 and for the PBAP and MAP Bluetooth® profiles. The prompt to confirm may take up to two minutes to be displayed. You may also save the confirmation on the mobile phone (see the manufacturer's operating instructions).

The mobile phone is now authorized and connected to Audio 20. You can now speak using the hands-free system.

To ensure an optimum language quality, you can set the mobile phone's transmission and reception volume (▷ page 64).

The code is different

- ▶ **Audio 20:** select **No**.

The process is canceled. Repeat the authorization.


Authorization via passkey entry (access code)

If Audio 20 has found your mobile phone, you can authorize (connect) it.

- ▶ To select the Bluetooth® name of the desired mobile phone in the device list: turn and press the controller.

The input menu for the passkey is displayed.

The passkey is a one- to sixteen-digit number combination which you can choose yourself.

- ▶ **Audio 20:** enter the passkey using the character bar.
- ▶ Select  once all the numbers have been entered.
- ▶ **Mobile phone:** enter the same passkey and confirm your entry. Depending on the mobile phone used, you may have to confirm the connection to Audio 20 and for the PBAP and MAP Bluetooth® profiles. The prompt to confirm may take up to two minutes to be displayed. You may also save the confirmation on the mobile phone (see the manufacturer's operating instructions). The mobile phone is now authorized and connected to Audio 20. You can now speak using the hands-free system.

To ensure an optimum language quality, you can set the mobile phone's transmission and reception volume (▷ page 64).


If the **Authorization Failed** message appears, you may have entered a different passkey or exceeded the prescribed time limit. Repeat the procedure.

- i** Some mobile phones require a passkey with four or more digits.

- i** If you wish to re-authorize the mobile phone after de-authorizing it, you can choose another passkey for it.

Establishing the connection from the mobile phone

The Bluetooth® device name of Audio 20 is "MB Bluetooth".

- ▶ **Audio 20:** call up the telephone menu.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Connect Device:** turn and press the controller.
The device list is displayed.
- ▶ To select **Connect via Phone:** turn and press the controller.
A message is displayed, stating that you can start the search on your mobile phone.
- ▶ **Mobile phone:** start the search for a Bluetooth® device (see manufacturer's operating instructions).
Audio 20 is displayed with the name "MB Bluetooth" in the mobile phone's device list.
- ▶ Select "MB Bluetooth".
A prompt appears in the Audio 20 display asking if the mobile phone should be authorized.
- ▶ **Audio 20:** select **Yes**.
If **No** is selected, the procedure is canceled.
If your mobile phone supports Secure Simple Pairing, a code is now displayed on both devices.

The code is the same

- ▶ **Audio 20:** select **Yes**.
- ▶ **Mobile phone:** confirm the code. Depending on the mobile phone used, you may have to confirm the connection to Audio 20 as well as confirm for the PBAP and MAP Bluetooth® profiles. The prompt to confirm may take up to two minutes to be displayed. You may also save the confirmation

on the mobile phone (see the manufacturer's operating instructions).

The mobile phone is now authorized and connected to Audio 20. You can now speak using the hands-free system.

To ensure an optimum language quality, you can set the mobile phone's transmission and reception volume (▷ page 64).

The code is different

- ▶ **Audio 20:** select **No**.
The process is canceled. Repeat the procedure.

If your mobile phone does not support Secure Simple Pairing, an input menu is displayed for the passkey. The passkey is a one- to sixteen-digit number combination which you can choose yourself. Enter the same passkey on both Audio 20 and the mobile phone and confirm. Depending on the mobile phone used, you may have to confirm the connection to Audio 20 and for the PBAP and MAP Bluetooth® profiles.



Reconnecting automatically

Audio 20 always searches for the last mobile phone connected.

If no connection can be made to the most recently connected mobile phone, the system searches for the mobile phone that was connected before that one.

Switching between mobile phones

If you have authorized more than one mobile phone, you can switch between the individual phones.

- ▶ To call up the telephone menu: press the  button.
- ▶ To show the menu bar: slide  the controller.

- ▶ To select **Connect Device**: turn and press the controller.
The device list is displayed.
- ▶ To select the desired mobile phone: turn and press the controller.
The selected mobile phone is searched for and connected if it is within Bluetooth® range and if Bluetooth® is activated.

Only one mobile phone can be connected at any one time. The currently connected mobile phone is indicated by the • dot in the device list.

- ❗ You can only switch to another authorized mobile phone if you are not currently making a call.

De-authorizing (disconnecting) a mobile phone

Mercedes-Benz USA, LLC recommends de-authorization in Audio 20 as well as in the mobile phone. Subsequent authorization may otherwise fail.

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To show the menu bar: slide **⊙↓** the controller.
- ▶ To select **Connect Device**: turn and press the controller.
- ▶ To highlight the desired mobile phone in the device list: turn the controller.
- ▶ To select **☰**: slide **⊙→** the controller.
- ▶ To select **Deauthorize**: turn and press the controller.
A prompt appears, asking whether you really wish to de-authorize this device.
- ▶ To select **Yes**: turn and press the controller.
The mobile phone is de-authorized.

- ❗ Before re-authorizing the mobile phone, you should also delete the device name **MB Bluetooth** from your mobile phone's Bluetooth® list.


Displaying connection details




- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar in the telephone menu: slide **⊙↓** the controller.
- ▶ To select **Connect Device**: turn and press the controller.
- ▶ To highlight the desired mobile phone in the device list: turn the controller.
- ▶ To select **☰**: slide **⊙→** the controller.
- ▶ To select **Details**: turn and press the controller.
The following information concerning the selected mobile phone is shown:
 - Bluetooth® device name
 - Bluetooth® address
 - availability status (shown after a new search)
 - authorization status
- ▶ **To close the detailed display**: slide **←⊙** the controller.

Reception and transmission volume

Once the mobile phone has been authorized, you can optimize the transmission and reception volume settings. To find out about the best possible settings for your mobile phone, visit **www.mercedes-benz-mobile.com**.

Or call the Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCEdes (1-800-367-6372) (USA) or Customer Relations at 1-800-387-0100 (Canada).




- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Connect Device**: turn the controller and press to confirm. The device list appears.
- ▶ To highlight the desired mobile phone in the device list: turn the controller.
- ▶ To select : slide  the controller.
- ▶ To select **Reception Volume** or **Transmission Volume**: turn and press the controller.
- ▶ To select a volume setting: turn the controller.
- ▶ To accept changes: press the controller.

i Incorrect settings may have an impact on the quality of calls.

Using the telephone

Accepting a call

- ▶ To select **Accept**: press the controller.
- or
- ▶ Press  on the multifunction steering wheel. The call is accepted.


Additional functions available during a call (▷ page 66).

Adjusting the call volume (▷ page 64).

Further information about ending a call (▷ page 68).


i If the phone number of the caller is transferred, it appears in the display. If the phone number is saved in the phone book, the contact's name is also displayed. If the phone number is not transferred, **Unknown** is shown in the display.

Rejecting a call

- ▶ To select **Reject**: turn the controller and press to confirm.
- or
- ▶ Press  on the multifunction steering wheel.

Making a call

Using the telephone menu

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To select all numbers one after the other in the telephone menu: turn and press the controller each time.
- ▶ To select  in the telephone menu: turn and press the controller. The call is made.


Further information about ending a call (▷ page 68).

Using favorites

This function can be used when a telephone number has been added as a favorite. Further information about adding favorites (▷ page 27).


- ▶ Press the favorites button on the controller. The favorites are displayed.
- ▶ To select a telephone number: turn the controller.
- ▶ To make a call: press the controller.

Redial

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To select  in the telephone menu: turn and press the controller. The list of outgoing calls is displayed. The most recently dialed number is at the top.
- ▶ To select an entry and make a call: turn and press the controller.

Further information about ending a call
(▷ page 68).

Using call lists

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Call Lists**: turn and press the controller.
- ▶ To select **Calls Received** or **Calls Dialed**: turn and press the controller. The relevant list is displayed.
- ▶ To select an entry and make a call: turn and press the controller.

Further information about ending a call
(▷ page 68).

Using the phone book

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To select **Name** in the telephone menu: turn and press the controller.
- ▶ Search for a contact (▷ page 69).
- ▶ To make a call: press the controller.

Further information about ending a call
(▷ page 68).

Using speed dial

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To highlight a number from the character bar: turn the controller.
- ▶ Press the controller for longer than two seconds. The telephone menu displays the selected entry. The number is dialed.

Further information on setting up speed dial
(▷ page 74).

Further information about ending a call
(▷ page 68).

Functions available during a call

Overview



- ① Person you are calling
- ② Symbol for active telephone connection
- ③ To end a call
- ④ To switch the microphone on/off (▷ page 67)
- ⑤ To send DTMF tones (not possible with all mobile phones) (▷ page 67)

Available functions:

- Accepting a waiting call (▷ page 68)
- Making a second call (▷ page 66)
- Call waiting (▷ page 67)


Availability depends on the network (only possible in the GSM network) and on the Bluetooth® mobile phone.

Adding a call

If the mobile phone network provider and the mobile phone support the function, you can make another call during an existing call. The previously active call is held.





- ① Adds a call

- ▶ To select ₂: turn and press the controller.
- ▶ Make a call:
 - Using the telephone menu (▶ page 65)
 - Redial (▶ page 65)
 - Using call lists (▶ page 73)
 - Using the phone book (▶ page 65)
 - Using speed dial (▶ page 65)


Switching the microphone on/off

This function is available in the telephone menu during an active phone call.

Switching off the microphone:

- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Microphone Off**: turn and press the controller.
If the microphone is switched off, the  symbol and the **The microphone is off.** message are displayed.

Switching on the microphone:

- ▶ Select **Microphone On**.
The  symbol disappears. The **The microphone is on.** message is shown.

Sending DTMF tones

This function is not supported by all mobile phones.

Answering machines or other devices can be controlled by DTMF tones, e.g. for remote query functions.

- ▶ If you would like to listen to the messages on your answering machine, for example, dial the corresponding number.

Transmitting individual characters:

- ▶ Once a connection has been established to the answer phone, select the desired characters in the telephone menu: turn and press the controller each time.
Every character selected will be transmitted immediately.

Calls with several participants



Switching between calls (call waiting)

If you make another call, you can switch between the two calls (call waiting). This function depends on your mobile phone network provider and the mobile phone (see the manufacturer's operating instructions).


The calls are marked 1 and 2. The active call is highlighted.




Switching between the calls:

- ▶ To select ₁ or ₂: turn and press the controller.


or

- ▶ Press  on the multifunction steering wheel.
The selected call is active. The other call is on hold.

Ending the active call:

- ▶ To select  in the telephone menu: turn and press the controller.

or

- ▶ Press  on the multifunction steering wheel.
The other call is still on hold.

- ▶ To activate the call on hold: select **ICON_Send Resume**.

The call on hold is activated. If you select **Hang Up**, the call on hold is also ended.

- ▶ **i** On some mobile phones, the call on hold is activated as soon as the active call is ended.

Conference call

You can interconnect active and held calls. This permits several parties to hear one another and speak with one another. This function depends on your mobile phone network provider and the mobile phone (see the manufacturer's operating instructions).




- ▶ Add a call (▷ page 66).
- or
- ▶ Answer an incoming call (▷ page 68).
- ▶ To select **Conference** in the telephone menu: turn and press the controller. The new participant is included in the conference call. **Conference** is displayed in the telephone menu.

Incoming call during an existing call (call waiting)

The call waiting function depends on your mobile phone network provider and your mobile phone. Depending on the mobile phone used, behavior when answering a call may vary (see the manufacturer's operating instructions).


Call waiting: if you receive a call while already in a call, a message is shown. You also hear a tone. You can decide whether to accept or reject the call.

Accepting:



- ▶ To select **Accept:** press the controller.
- or
- ▶ Press  on the multifunction steering wheel. The incoming call is active, the previously active call is on hold. You can switch back and forth between both calls (call waiting) (▷ page 67).

i Depending on the mobile phone, you may also be able to accept the incoming call (call waiting) on your mobile phone. This function and behavior depends on your mobile phone network provider and the mobile phone (see the manufacturer's operating instructions).

Rejecting:

- ▶ To select **Reject:** turn the controller and press to confirm.
- or
- ▶ Press  on the multifunction steering wheel. The behavior after the call is rejected depends on your mobile phone and mobile phone network provider.
 - Option 1: The originally active call is continued and the incoming call is rejected.
 - Option 2: The originally active call is ended and the incoming call is accepted.
 - Option 3: Both calls are ended.

Ending an active call

- ▶ To select  in the telephone menu: turn and press the controller.
- or
- ▶ Press  on the multifunction steering wheel. The active call is ended.

Phone book

Introduction

The telephone book displays all the contacts. The mobile phone's telephone book is automatically displayed in Audio 20 after connection (default setting). You can deactivate automatic calling up (▷ page 70).

In the telephone book, you can:

- Search for contacts (▷ page 69)
- Store contacts (▷ page 71)
- Delete contacts (▷ page 71)

Further information on importing contacts (▷ page 71).

- i** Between 1000 and 2000 contacts can be stored permanently in the phone book.





When you import or save contacts, they will be permanently saved in Audio 20. These contacts will remain there even when you connect Audio 20 to a different mobile phone. You can view these contacts even without a mobile phone.

You can now search for a contact (▷ page 69).


Further information on the symbols shown (▷ page 69).

- i** You can also call up the telephone book with the multifunction steering wheel (see the separate operating instructions).

Symbol overview

Symbol	Explanation
	Contact that was saved on Audio 20.
	Contact that was called up from a mobile phone
	Contact imported from a USB device.
	Contact imported via the Bluetooth® interface.

Calling up the phone book



P82.89-0193-31

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To select **Name** in the telephone menu: turn and press the controller. If the phone book contains contacts, they will be displayed in alphabetical order. The character bar at the bottom of the display is active.

Searching for a contact

Using the character bar




P82.89-0193-31

You determine the first letter of the contact you are looking for with the first character you enter.

- ▶ To select characters: turn the controller and press to confirm. The first contact with the selected first character is highlighted in the phone book.

If there are similar contacts, the next different character is shown. For example, with contacts such as **Jana** and **John**, the beginnings of the names are identical. The next different character **A** and **O** are offered for selection.

- ▶ Select the characters of the contact you are searching for one by one, pressing and confirming with the controller each time.
- ▶ To select  : turn and press the controller. The contacts in the phone book are displayed.
- ▶ To select a contact: turn and press the controller.

If a contact contains more than one phone number:

- ▶ To select and call a telephone number: turn and press the controller.

Back to the character bar:

- ▶ Press the  button repeatedly until the character bar is displayed.

Using the touchpad

You determine the first letter of the contact you are looking for with the first character you enter.

- ▶ Draw the letter on the touchpad surface. The first contact with the selected first character is highlighted in the phone book. Further information on handwriting recognition on the touchpad (> page 23).
- ▶ Draw additional letters on the touchpad surface one after another.
- ▶ To complete the search and return to the phone book: press the touchpad.
- ▶ To select the contact: glide up or down and press. The contact's phone number is displayed.

If a contact contains more than one phone number:

- ▶ To select and call the sub-entry: glide up or down and press.



Displaying the details of a contact

- ▶ To select a contact in the phone book: turn and press the controller.
- ▶ To select **Details**: turn and press the controller. The detailed view appears.

Closing the detailed display:

- ▶ To select : slide  the controller.

Changing the display and sorting criteria for contacts


- ▶ To call up the telephone menu: press the  button.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Options**: turn and press the controller.
- ▶ To select **Display and Sorting**: turn and press the controller.

You have the following options:


- **Last Name, First Name** (default setting)
The contacts are sorted by surname and displayed with a comma.
- **Last Name First Name**
The contacts are sorted by surname and displayed without a comma.
- **First Name Last Name**
The contacts are sorted by first name and displayed without a comma.
- ▶ To select the required option: turn and press the controller. The contacts are sorted and displayed according to the selection.

Automatically importing contacts from the mobile phone

Depending on the mobile phone used, you can set whether the contacts should be called up automatically after the mobile phone is connected to Audio 20.





- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Options**: turn and press the controller.
- ▶ To select **Automatically Import Contacts from Phone**: turn and press the controller.
You can allow or deactivate the automatic download.


If the function is deactivated, the contacts can be called up manually:

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Options**: turn and press the controller.
- ▶ To select **Call up Contacts**: turn the controller and press to confirm.
The contacts are called up.

Saving a contact



Saved contacts are indicated in the phone book by different symbols (▷ page 69).

- ▶ Search for a contact on the mobile phone  (▷ page 69).
- ▶ To select : slide  the controller.
- ▶ To select **Save**: turn and press the controller.
The contact has now been saved. The contact is identified by the  symbol in the phone book.

- i** Saving the contact data on Audio 20 does not change the contacts on the mobile phone. If automatic calling up of phone contacts is activated, Audio 20 displays the copy  with the changed data.

Deleting a contact

You can delete contacts that have been saved or imported in Audio 20.

- ▶ To highlight a contact in the phone book: turn the controller.
 - ▶ To select : slide  the controller.
 - ▶ To select **Delete Contacts**: turn and press the controller.
A prompt appears asking whether the contact should be deleted.
 - ▶ To select **Yes**: turn and press the controller.
The phone number is deleted.
- or
- ▶ To select **No**: turn and press the controller.
The process is canceled.

Importing contacts

Information and requirements

You can import contacts (vCards) into the phone book via memory card, USB or Bluetooth®.


- i** Between 1000 and 2000 contacts can be imported into the phone book. A message notifies you when the maximum number is reached. In order to be able to then import new contacts, you have to delete existing contacts (▷ page 71).

Source	Prerequisites
Memory card	The SD memory card is inserted. It contains importable contact details.

USB device	The USB device is inserted into the USB port. It contains importable contact details.
Bluetooth® connection	If the sending of vCards is supported via Bluetooth®, vCards can be received on mobile phones or net-books, for example. Bluetooth® must be activated in Audio 20 and on the respective device (see the manufacturer's operating instructions).

- i** If automatic calling up of the contacts is deactivated (> page 70), the **Import from Phone** option is available.



Importing from the memory card or USB device

Contacts imported from the memory card or from a USB device are identified by the  symbol.

The following conditions must be fulfilled in order to import vCards:

- vCards (vcf files) may be located in the main directory or in folders. Audio 20 allows you to select the relevant folders directly.
- vCards must have the file extension ".vcf".



- i** vcf files may also contain multiple vCards. Audio 20 supports vCards in versions 2.1 and 3.0.

- ▶ To call up the telephone menu: press the  button.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Options**: turn and press the controller.
- ▶ To select **Download Contacts**: turn and press the controller.
A menu appears.

- ▶ To select **From Memory Card, USB 1** or **USB 2** in the menu: turn and press the controller.

Receiving vCards via Bluetooth®

Audio 20:

- ▶ To call up the telephone menu: press the  button.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Options**: turn and press the controller.
- ▶ To select **Download Contacts**: turn and press the controller.
- ▶ To select **From Bluetooth Device**: turn and press the controller.


If Audio 20 is connected to a mobile phone, the connection is terminated. vCards can now be received by a device (PC, mobile phone) via Bluetooth®.

External device:

- ▶ Start the data transfer (see the manufacturer's operating instructions).
The number of vCards received is displayed in Audio 20.



Audio 20:

- ▶ To cancel the transfer: press the controller.
If a mobile phone was connected, the connection to the mobile phone is established again.

Received vCards are identified by the  symbol in the phone book.



- i** If you switch to another main function, e.g. radio, while receiving vCards, the reception of vCards will be terminated.

Deleting imported contacts

- ▶ To call up the telephone menu: press the  button.
- ▶ To switch to the menu bar: slide  the controller.

- ▶ To select **Options**: turn and press the controller.
 - ▶ To select **Delete Contacts**: turn and press the controller.
 - ▶ Select one of the following options:
 - **Internal Contacts**
 - **Imported from Storage Device**
 - **Imported from BT Devices**
 - **Downloaded from Phone**
 Turn and press the controller.
 - ▶ To select **Yes**: turn and press the controller. The contacts are deleted.
- or
- ▶ To select **No**: turn and press the controller. The process is canceled.

Closing the phone book

- ▶ To select  from the character bar: turn the controller and press to confirm.
- or
- ▶ Press the  button.

Call lists

Introduction

If your mobile phone supports the PBAP Bluetooth® profile, the call lists from the mobile phone are displayed in Audio 20. When connecting the mobile phone, you may have to confirm the connection for the PBAP Bluetooth® profile.

If your mobile phone does not support the PBAP Bluetooth® profile, Audio 20 generates its own call lists. These are not the same as the call lists in your mobile phone.

The Call list option is not available unless a mobile phone is connected to Audio 20.



- i** If you connect a different mobile phone to Audio 20, the call lists from the new mobile phone are displayed.

Opening the call list and selecting an entry





List of selected phone numbers (example)


- ① Date and time (if available)
- ② Telephone number of the highlighted entry and symbols (if assigned)


- ▶ To call up the telephone menu: press the  button.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Call Lists**: turn and press the controller.
- ▶ To select **Calls Received** or **Calls Dialed**: turn and press the controller. The relevant list is displayed.
- ▶ To select an entry and make a call: turn and press the controller.

Closing the call list

- ▶ To select  to the left of the list: slide  the controller.

or

- ▶ Press the  button. The list is closed.

- i** You can also call up the list of dialed numbers by pressing the  button when the telephone menu is shown. In this case, the list will only show names or phone numbers.

Displaying details from a list entry

Abbreviated list entries can also be shown in full.

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar: slide the controller.
- ▶ To select **Call Lists**: turn and press the controller.
- ▶ To select **Calls Received** or **Calls Dialed**: turn and press the controller. The relevant list is displayed.
- ▶ To highlight the desired entry: turn the controller.
- ▶ To select : slide the controller.
- ▶ To select **Details**: turn and press the controller. The details are displayed.
- ▶ To go back to the list: slide the controller repeatedly until the list is highlighted.

Speed dial lists

Setting up

- ▶ Call up the phone book (> page 69).
- ▶ Search for and select a contact (> page 69).
- ▶ To highlight the telephone number: turn the controller.
- ▶ To select : slide the controller.
- ▶ To select **Assign Speed Dial Preset**: turn and press the controller. The speed dial list is displayed.
- ▶ To select a memory position for the speed dial: turn and press the controller.
If you select an entry that already exists in the speed dial list, this is overwritten with the new entry.
The phone number has been saved as a speed dial.

Deleting

Deleting a speed dial preset


- ▶ To call up the telephone menu: press the **TEL** button.
 - ▶ To call up the menu bar: slide the controller.
 - ▶ To select **Call Lists**: turn and press the controller.
 - ▶ Select **Speed Dial Preset List**. The speed dial list is displayed.
 - ▶ To highlight the memory position you want to delete: turn the controller.
 - ▶ To select : slide the controller.
 - ▶ To select **Delete Speed Dial Preset**: turn and press the controller.
 - ▶ To select **Yes**: turn and press the controller. The speed dial preset has been deleted.
- or
- ▶ To select **No**: turn and press the controller. The process is canceled.

Deleting all speed dial presets

- ▶ To call up the telephone menu: press the **TEL** button.
 - ▶ To call up the menu bar: slide the controller.
 - ▶ To select **Call Lists**: turn and press the controller.
 - ▶ Select **Speed Dial Preset List**. The speed dial list is displayed.
 - ▶ To highlight the desired memory position: turn the controller.
 - ▶ To select : slide the controller.
 - ▶ To select **Delete All Speed Dial Presets**: turn and press the controller.
 - ▶ To select **Yes**: turn and press the controller. All speed dials are deleted.
- or
- ▶ To select **No**: turn and press the controller. The process is canceled.

Messages (text messages and e-mails)

General notes

New messages are identified by an audible signal and the  symbol in the Audio display. Once you have read all the messages, the symbol is no longer displayed.

Audio 20 displays the 100 newest text messages.

Prerequisites

To use the message functions, the connected mobile phone must support the MAP Bluetooth® profile (see the manufacturer's operating instructions). The prompt for the MAP Bluetooth® profile may have to be confirmed on the mobile phone.

Some mobile phones with the MAP Bluetooth® profile only show new text messages or do not send messages when locked.





With some mobile phones, some settings still have to be made after connecting to Audio 20 (see the manufacturer's operating instructions). The messages are displayed the next time you connect to Audio 20.

Not all mobile phones available on the market are equally suitable. You can obtain further information about settings and supported functions of Bluetooth®-capable mobile phones on the Internet at <http://www.mbusa-mobile.com>.

Or call the Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCEDES (1-800-367-6372) (for the USA) or Customer Relations at 1-800-387-0100 (for Canada).

Settings

Calling up the settings menu for messages

- ▶ To call up the telephone menu: press the  button.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select : turn and press the controller. The message menu appears.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Settings**: turn and press the controller. The text message settings are displayed.

Configuring the text messages displayed

- ▶ Call up the settings menu for messages (▷ page 75). A menu with the following options is shown:
 - **All Messages**
All the messages are displayed.
 - **New Messages**
Only the messages that are new on the mobile phone are displayed. You can also display the last 100 text messages using the **Download** option in the message menu.
 - **Off**
The messages are not displayed automatically. You can display the 100 newest text messages from the mobile phone using the **Download** option in the message menu.
- ▶ To select the required option: turn and press the controller.

Downloading messages manually

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar: slide **⊙↓** the controller.
- ▶ To select **✉**: turn and press the controller. The message menu is displayed.
- ▶ To switch to the menu bar: slide **⊙↓** the controller.
- ▶ To select **Download**: turn and press the controller. The messages are downloaded.

If you have selected **New Messages** or **Off** in the text message settings, manual downloading is possible.


Reading messages

In the message menu

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar: slide **⊙↓** the controller.
- ▶ To select **✉**: turn and press the controller. The message menu is displayed with the unread messages.
- ▶ To select the message: turn and press the controller. The message text is displayed.
- ▶ To close the message text: press the **⏪** button.

If you want to read messages that have already been read again, you have to call up the text message folder (▷ page 76).

In the message folder








- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar: slide **⊙↓** the controller.
- ▶ To select **✉**: turn and press the controller. The message menu is displayed.
- ▶ To switch to the menu bar: slide **⊙↓** the controller.
- ▶ To select **Text Message**: turn and press the controller. The text message folder is displayed.
- ▶ To select the message: turn and press the controller. The message is displayed.
- ▶ To scroll through the message or select phone numbers in the text: turn the controller. The display scrolls up or down line by line, or skips to the next or previous telephone number and automatically highlights it.
- ▶ To return to the list: press **⏪**.

Displaying details and phone numbers

Audio 20 can also show the full details instead of the shortened sender display.

- ▶ To call up the telephone menu: press the **TEL** button.
- ▶ To switch to the menu bar: slide **⊙↓** the controller.
- ▶ To select **✉**: turn and press the controller. The message menu is displayed.
- ▶ To switch to the menu bar: slide **⊙↓** the controller.

- ▶ To select **Text Message**: turn and press the controller.
The text message folder is displayed.
 - ▶ To highlight the desired message: turn the controller.
 - ▶ To select : slide  the controller.
 - ▶ To select **Details**: turn and press the controller.
The detailed view appears.
 - ▶ **To close the detailed display**: slide  the controller.
 - ▶ **To return to the telephone menu**: press the **BACK** button.
- ▶ To select : slide  the controller.
 - ▶ To select **Delete**: turn and press the controller.
 - ▶ To select **Yes**: turn and press the controller.
The message is deleted.
- or
- ▶ To select **No**: turn and press the controller.
The process is canceled.
- i** This delete function is not supported by all mobile phones. The **Delete failed.** message then appears.

Calling a text message sender

- ▶ Display the message (▷ page 76).
- ▶ To call up a menu: press the controller.
- ▶ To select **Call Sender**: turn and press the controller.
The call is made.

Using a phone number in the text

Numbers in text messages that are highlighted can be used.

- ▶ To select a usable phone number while the message is displayed: turn and press the controller.
- ▶ To select **Call Number**: turn and press the controller.
The call is made.

- i** It is possible that a highlighted numerical sequence may not contain a telephone number.

Deleting messages

- ▶ Call up the text message folder (▷ page 76).
- ▶ To select the message: turn and press the controller.

Audio 20 features	80
Important safety notes	80
General notes	80
Conditions for access	80
Setting up an Internet connection (Canada)	81
Establishing/ending the connection	85
Google™ local search	85
Destination/route download	88
Further Mercedes-Benz Apps	90
Web browser	92

Audio 20 features

- i** These operating instructions describe all the standard and optional equipment of your Audio 20 system, as available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions.
- i** Read the information on qualified specialist workshops in the vehicle Operator's Manual.

Important safety notes

WARNING

If you operate information systems and communication equipment integrated in the vehicle while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident. Only operate the equipment when the traffic situation permits. If you are not sure that this is possible, park the vehicle paying attention to traffic conditions and operate the equipment when the vehicle is stationary.

You must observe the legal requirements for the country in which you are driving when operating the system.

General notes

Connection difficulties while the vehicle is in motion

The connection may be lost if:

- the mobile phone network coverage is insufficient
- the vehicle has moved into a mobile phone cell with no free channels
- the SIM card used is not compatible with the network available

Function restrictions (Canada)

You will not be able to use the Mercedes-Benz Apps and Internet connection, or will no longer be able to use them, or may have to wait before using them, in the following situations:

- when the mobile phone is switched off
- if your mobile phone has not been enabled for Internet access
- if the Bluetooth® function is switched off on Audio 20 and the desired phone is to be connected via Bluetooth®
- if the Bluetooth® function is switched off on the mobile phone and the phone is supposed to be connected via Bluetooth®
- if neither the mobile phone network nor the mobile phone allow simultaneous use of a phone and an Internet connection
- if the mobile phone has not been enabled for Internet access via Bluetooth®

The driver is not permitted to call up websites while driving and use of the Mercedes-Benz Apps is restricted.

- i** It is possible that you may not be able to receive calls when an Internet connection is active. This depends on the mobile phone and the mobile phone network used.

Conditions for access

USA: to use Mercedes-Benz Apps and Internet access, mbrace must be activated and operational. Furthermore, mbrace must be activated for Mercedes-Benz Apps and Internet access. Take note of the connection priorities. An emergency call has the highest priority. When a service call, e.g. a breakdown service call or the MB Info Call, is active, an emergency call can still be initiated. A service call, on the other hand, has priority over a current Internet connection. Therefore, you cannot establish an Internet connection during a service call.

Canada: a mobile phone must be connected via Bluetooth® (▷ page 60) with Audio 20. Furthermore, you need a valid mobile service contract with a data option, which is used to calculate the associated connection costs.

Conditions for a Bluetooth® connection

- The mobile phone supports at least one of the Bluetooth® profiles DUN (Dial-Up Networking) or PAN (Personal Area Network).

The Bluetooth® profiles DUN and PAN enable the Internet connection of the mobile phone to be made available to the system.

The terms of use are shown when the system is used for the first time and then once a year thereafter. Only read and accept the terms of use when the vehicle is stationary.

The driver is not permitted to call up websites while driving and use of the Mercedes-Benz Apps is restricted.

- ❗ The availability of individual Mercedes-Benz Apps may vary depending on the country.


Setting up an Internet connection (Canada)


Procedure and general information

If you are using Internet access for the first time, you must enable the connected mobile phone for Internet access (▷ page 81). If the connected mobile phone supports the Bluetooth® PAN profile, you do not need to make additional settings. The Internet connection is established. If the connected mobile phone does not support the named Bluetooth® profile, predefined (▷ page 82) or manual access data (▷ page 82) must be set.

While initializing the mobile phone for the Internet connection, access data which is already on the mobile phone may be overwritten. You should therefore check the settings on the mobile phone (see the manufacturer's operating instructions).

Enabling the mobile phone for Internet access

- ▶ To display the main function bar: slide ↑⊙ the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To switch to the menu bar: slide ⊙↓ the controller.
- ▶ To select **Settings**: turn and press the controller.
- ▶ To select **Configure Internet Settings**: turn and press the controller. A message is displayed telling you that the settings for the Internet functions depend on your mobile phone network provider and your mobile phone.
 - If a mobile phone has already been enabled, the device list is displayed.
- ▶ To select **Start Search**: turn and press the controller. Mobile phones are displayed that:
 - are connected with Audio 20
 - fulfill the conditions for the Internet functions
 - have not yet been set up for the Internet function




- ▶ To select a mobile phone from the device list: turn the controller and press to confirm. If the mobile phone supports the Bluetooth® PAN profile, Internet access is set up. You can use the Internet functions.

If the connected mobile phone does not support the named Bluetooth® profile, predefined (▷ page 82) or manual access data (▷ page 82) must be set.

Setting access data of the mobile phone network provider

Selecting the predefined access data of the mobile phone network provider



- ▶ To select **Predefined Settings**: turn and press the controller.
A list of countries appears.

If the mobile phone network provider provides multiple access data options, the relevant access data still has to be selected. This depends on the data package used, for example.


To check whether the predetermined dial-in data corresponds with the dial-in data provided by your mobile phone network provider, proceed as follows (▷ page 84) and select **Manual Settings**. The access data is displayed.

The access data for the mobile phone network provider is selected once for the mobile phone connected and is loaded again each time the mobile phone is connected. Establishing a connection (▷ page 85).

You must set the access data of the mobile phone network provider who provides the SIM card and the associated data package (access settings) for the connected mobile phone. The access data remains the same when you are in a different country (roaming).

The access data of another network is **not** selected.

Manually setting the access data of the mobile phone network provider




- ▶ To select **Manual Settings**: turn and press the controller.
An overview of the provider settings appears.
- ▶ Set access data (▷ page 83).
- ▶ To confirm settings: select **Confirm Settings** and turn and press the controller.

The access data for the mobile phone network provider is selected once for the mobile phone connected and is loaded again each time the mobile phone is connected. Establishing a connection (▷ page 85).

You must set the access data of the mobile phone network provider who provides the SIM card and the associated data package (access settings) for the connected mobile phone. The access data remains the same when you are in a different country (roaming). The access data of another network is **not** selected.

Setting access data



P82.89-0553-31

Set the access data in accordance with your data package. You can contact your mobile phone network provider to obtain the precise access data.


Explanation of the access data

Input field	Meaning
Phone Number:	Access number for establishing the connection The access number depends on the mobile phone used. For GSM/UMTS mobile phones, *99***1# is used as a standard.
Access Point:	APN network access point (Access Point Name) You can obtain this information from your mobile phone network provider. Entry is not necessary for all mobile phone network providers and mobile phones.
PDP Type:	Internet protocol used. You can obtain this information from your mobile phone network provider.






Input field	Meaning
User ID:	The user identification can be obtained from your mobile phone network provider. Entry is not necessary for all mobile phone network providers.
Password:	The password can be obtained from your mobile phone network provider. Entry is not necessary for all mobile phone network providers.
Auto DNS:	Automatic allocation of DNS servers is activated. If the function is deactivated, the DNS server addresses must be entered manually. DNS (Domain Name Service)
DNS1: DNS2:	Fields for entering the DNS server addresses manually. The address can be obtained from your mobile phone network provider.

Managing existing access data

Calling up the device list



P82.87-9617-31



- ▶ To display the main function bar: slide  the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select **Settings**: turn and press the controller.
- ▶ To select **Configure Internet Settings**: turn and press the controller. The device list is displayed.
- ▶ To select : slide  the controller.
- ▶ To select **Delete Configuration**: turn and press the controller. A prompt appears asking whether you wish to delete the Internet configuration.
- ▶ To select **Yes**: turn and press the controller. The Internet access permission for the mobile phone is now canceled. The mobile phone can now no longer be used by the system for Internet functions.

or

- ▶ To select **No**: turn and press the controller. The process is canceled.

Editing the access data

The mobile phone must be connected with the system for the access data to be changed. When the Internet connection is active, you cannot edit or delete the access data of the currently set mobile phone network provider.

- ▶ Call up the device list (▷ page 83).
- ▶ To highlight the desired mobile phone in the device list: turn the controller.
- ▶ To select : slide  the controller.
- ▶ To select **Change Configuration**: turn and press the controller.
- ▶ Select **Predefined Settings** or **Manual Settings**.

The provider settings are displayed.




In order to edit the access data of the mobile phone network provider you have two options:

- Option 1: select the predefined access data of the mobile phone network provider (▷ page 82).
- Option 2: manually set the access data of the mobile phone network provider (▷ page 82).

Canceling Internet access permissions for a mobile phone



- ▶ Call up the device list (▷ page 83).
- ▶ To highlight the desired mobile phone in the device list: turn the controller.

Changing the device name of the mobile phone

- ▶ Call up the device list (▷ page 83).
- ▶ To highlight the desired mobile phone in the device list: turn the controller.
- ▶ To select : slide  the controller.
- ▶ Select **Change Internet Device Name**. A character entry appears.
- ▶ Enter name and confirm with  . The device name is changed.

Setting automatic disconnection of the Internet connection

If a preset time has elapsed during which the Internet functions have not been used, the Internet automatically disconnects.

- ▶ Call up the device list (▷ page 83).
- ▶ To highlight the desired mobile phone in the device list: turn the controller.
- ▶ To select : slide  the controller.
- ▶ To select **Disconnect When Inactive**: turn and press the controller.
- ▶ To select **5 Minutes**, **10 Minutes**, **20 Minutes** or **Never**: turn and press the controller.

Establishing/ending the connection

Establishing the connection

Read the conditions for establishing a connection (▷ page 80).

A connection can be established by:

- entering a web address (▷ page 92)
- calling up the Mercedes-Benz mobile website (▷ page 90)
- calling up a Mercedes-Benz App (▷ page 90)
- calling up a favorite

Ending the connection

- ▶ Press **Cancel** in the connections window.

Connection status



- ① Display of existing connection and signal strength of the mobile phone network

In most cases, the current connection status is then shown in the status bar when you switch to another main function.

Detailed connection status

- ▶ To display the main function bar: slide ↑⊙ the controller.
- ▶ To select **⊕**: turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To switch to the menu bar: slide ⊙↓ the controller.

- ▶ To select **Settings**: turn and press the controller.
- ▶ To select **Connection Status**: turn and press the controller. The following information is displayed:
 - the volume of transferred data
 - connection status
 - the device name of the mobile phone

Ending the connection

USA: you cannot cancel the connection yourself. The Internet connection is automatically terminated if the system does not recognize any user input within a five-minute time period.


Canada:

- ▶ To display the main function bar: slide ↑⊙ the controller.
- ▶ To select **⊕**: turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To switch to the menu bar: slide ⊙↓ the controller.
- ▶ To select the scissors symbol: turn and press the controller.



If the mobile phone Internet connection is disconnected, Audio 20 tries to reconnect. You should therefore always close the connection on Audio 20.

Google™ local search

Calling up Local Search




You do not need a Google™ account to use Local Search.

- ▶ To display the main function bar: slide  the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To select **Mercedes-Benz Apps**: turn and press the controller.
- ▶ To select **Google Local Search**: turn and press the controller.

Further information on how to enter the search position and search term ([▷ page 86](#)).

- i** You will first need to register Audio 20 before you can use the Internet functions. To do so, you have to enter your name and postal address once in the vehicle and confirm the general terms and conditions.

Entering a search position and search term



It is only possible for the driver to enter a search term when the vehicle is stationary.

The following options are available for Local Search:

- **At the current location**
Searches for destinations near the current vehicle position
- **In the Vicinity of the Destination**

You can search for destinations in the vicinity of the destination if route guidance is active.

- **At another location**
Searches for destinations near the location
- i** You can also select a destination from the general search history.
- ▶ To select the required option: turn and press the controller.
- ▶ To select **Enter search term**: turn and press the controller.
The input menu for the search term is displayed.
- ▶ To complete the entry and start the search, select **OK**: turn and press the controller. The search results are displayed.
- i** Google™ determines how the search results are sorted; this is not necessarily based on the shortest distance.

Further information on how to make use of a search result ([▷ page 86](#)).

Using search results

- ▶ To select a search result: turn and press the controller.
A menu appears.

Displaying details

- ▶ Select **Details**.
The address of the selected entry is displayed.

Using a search result as a destination

- ▶ Select **Set as Destination**.
The navigation is called up. You can use the search result as the destination for route calculation.
- i** At the same time the search result is stored in the "Last destinations" memory. You can take the destination from this memory and save it permanently in the contacts.

Calling up a destination

- ▶ Select **Call**.
The telephone menu is called up and a call is activated.
- ▶ **i** If there is no phone number available, the menu item cannot be selected.


Calling up Google Street View™

- ▶ Select **Google Street View**.
Google Street View™ is called up.
- ▶ **i** If no Google Street View™ information is available, a corresponding message appears.

Calling up Panoramio by Google™

- ▶ Select **Panoramio by Google**.
Panoramio by Google™ is called up. You see pictures of places worth seeing in the vicinity of the search result.

Popular searches



You can use this function if search queries have already been carried out. If the vehicle is stationary, the search results can be supplemented manually, e.g. "Hotel Adler".

- ▶ Call up Local Search (▷ page 85).
- ▶ To select the search position, e.g. **At current location**: turn and press the controller.
- ▶ To select **Popular searches**: turn and press the controller.
The most frequent search queries are displayed.

Search history


You can use this function if search queries have already been carried out.

If the vehicle is stationary, the search results can be supplemented manually, e.g. "Hotel Adler".

- ▶ Call up Local Search (▷ page 85).
- ▶ To select the search position, e.g. **At current location**: turn and press the controller.
- ▶ To select **Search history**: turn and press the controller.
The most recent search queries are displayed.

Local Search settings

Calling up settings



- ▶ To display the main function bar: slide **↑** the controller.
- ▶ To select **🌐**: turn and press the controller.
The menu with the Internet functions is displayed.
- ▶ To select **Mercedes-Benz Apps**: turn and press the controller.
- ▶ To select **Google Local Search**: turn and press the controller.
- ▶ To select **☰**: slide **⊙** the controller.
The current settings are displayed.

Setting the search radius

- ▶ Call up Local Search settings (▷ page 87).
- ▶ To select **Search radius**: turn and press the controller.
A menu appears.
- ▶ To select the desired entry: turn and press the controller.
The selected setting is accepted.

Exiting a menu

- ▶ Select .

Resetting last location searches

- ▶ Call up Local Search settings (▷ page 87).
 - ▶ To select **Reset last location searches**: turn the controller and press to confirm.
A prompt appears asking whether the last location searches should be deleted.
 - ▶ To select **Yes**: turn and press the controller.
The search queries are deleted.
- or
- ▶ To select **No**: turn and press the controller.
The process is canceled.

Deleting search queries

- ▶ Call up Local Search settings (▷ page 87).
 - ▶ To select **Delete all searches**: turn the controller and press to confirm.
A prompt appears, asking whether the last search queries should be deleted.
 - ▶ To select **Yes**: turn and press the controller.
The last search queries are deleted.
- or
- ▶ To select **No**: turn and press the controller.
The process is canceled.

Destination/route download

Prerequisites

To download navigation locations you need a Google™ account and your vehicle identification number. Further information about the

vehicle identification number (VIN) (▷ page 90).

To download navigation locations, the mbrace system must be:

- activated
- operational
- activated for the services of the system and for Internet access

For information on the mbrace system, see the separate vehicle Operator's Manual.

Procedure and general information

Sign into your Google™ account on the Internet. Use the Google Maps™ website to send the destination to a server (▷ page 88). Using the **Download POI** App, the destination is displayed in the vehicle (▷ page 89).

The destination can be:

- used for route guidance (▷ page 89)
- called up (▷ page 89)
- deleted from the server (▷ page 90).


Sending destinations to the server

- ▶ Sign into your Google™ account.
 - ▶ Call up the Google Maps™ website.
 - ▶ Enter a destination.
 - ▶ Click "More" at the destination.
 - ▶ Click "Send".
 - ▶ Enter the corresponding information in the boxes shown.
 - ▶ Select "Send to car".
 - ▶ Select Mercedes-Benz as the vehicle brand.
 - ▶ Enter the mbrace e-mail address or the vehicle identification number.
- Further information about the vehicle identification number (▷ page 90).
- ▶ Click "Send".

The destination is sent to the server.

The availability of the destination/route download function is country-dependent.

Displaying destinations in the vehicle



- ▶ To display the main function bar: slide the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To select **Mercedes-Benz Apps**: turn and press the controller.
- ▶ To select **Download POI**: turn and press the controller. Available destinations are shown in the list.
- ▶ To select and download a destination: turn and press the controller.
- ▶ To exit destination download: select **Close**.


Further information on how to use the destination for route guidance (▷ page 89).

Further information on deleting the destination (▷ page 90).

You can save up to 50 destinations for your vehicle on the server and display these in the list. If you send further destinations to the server, the oldest entries are deleted from the list.

Using destinations

Displaying details



- ▶ Display the destination in the vehicle (▷ page 89).
- ▶ To highlight a destination: turn the controller.
- ▶ To select : slide the controller.
- ▶ To select **Details**: turn and press the controller. The destination address is shown.



Using a destination for route guidance

- ▶ Display the destination in the vehicle (▷ page 89).
- ▶ To highlight a destination: turn the controller.
- ▶ To select : slide the controller.
- ▶ To select **Set as Destination**: turn and press the controller. You then switch to navigation mode and can start route calculation. The destination is entered in the list of last destinations.

Calling up the destination



You can use the function if:

- a mobile phone is connected (▷ page 60)
- the destination address contains a telephone number


- ▶ Display the destination in the vehicle (▷ page 89).
- ▶ To highlight a destination: turn the controller.
- ▶ To select : slide  the controller.
- ▶ Select **Call**.
You then switch to the telephone function and make the call (▷ page 65).



Deleting a destination from the server



Destinations on the server are automatically deleted after seven days.

- ▶ Display the destination in the vehicle (▷ page 89).
 - ▶ To highlight a destination: turn the controller.
 - ▶ To select : slide  the controller.
 - ▶ Select **Delete**.
A prompt appears asking whether the destination should be deleted.
 - ▶ To select **Yes**: turn and press the controller.
The phone number is deleted.
- or
- ▶ To select **No**: turn and press the controller.
The process is canceled.


Displaying the vehicle identification number (VIN)



- ▶ To display the main function bar: slide  the controller.
- ▶ To select : turn and press the controller.
The menu with the Internet functions is displayed.

- ▶ To select **Mercedes-Benz Apps**: turn and press the controller.
- ▶ To highlight **Download POI**: turn the controller.
- ▶ To select : slide  the controller.
The vehicle identification number is displayed.

Exiting a menu

- ▶ Press the  button.


Further Mercedes-Benz Apps

General notes

To be able to use Mercedes-Benz Apps, you first have to register. To do so, you have to enter your name and postal address once in the vehicle and confirm the general terms and conditions. A message to this effect appears the first time you call up the online and Internet functions.



For individual Mercedes-Benz Apps, it may be necessary to pay license fees before using. Use is then limited to a certain period of time. License fees must be paid again for use beyond this time period.

Mercedes-Benz Mobile Website





Connecting to the Internet: (▷ page 85)

The online functions contain the Mercedes-Benz Mobile Website as a predefined favorite.



- ▶ To display the main function bar: slide  the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ Select the **Mercedes-Benz Mobile Website** menu. The Mercedes-Benz home page appears.
- i** You cannot delete the **Mercedes-Benz Mobile Website** menu.

Calling up Mercedes-Benz Apps





- ▶ To display the main function bar: slide  the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To select **Mercedes-Benz Apps**: turn and press the controller. The available **Mercedes-Benz Apps** are displayed.
- ▶ To select the desired app: turn and press the controller.

Additional Mercedes-Benz Apps can be purchased on the Mercedes-Benz website. You can find further information at: <http://apps.mercedes-benz.com/apps/> The available features are country-dependent.

Closing Mercedes-Benz Apps





- ▶ Press the  button. The Internet menu appears.
- or
- ▶ Press the  button for longer than two seconds. The Mercedes-Benz Apps menu or the Internet menu appears.

Adjusting the settings of individual apps

- ▶ To display the main function bar: slide  the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To select **Mercedes-Benz Apps**: turn and press the controller.
- ▶ To highlight the desired app: turn the controller.
- ▶ To select : slide  the controller. The current app settings are displayed.

Resetting adjustments

With the reset function, all Mercedes-Benz Apps settings are reset to the factory settings.

- ▶ To display the main function bar: slide  the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To select **Mercedes-Benz Apps**: turn and press the controller. The available **Mercedes-Benz Apps** are displayed.
- ▶ To select : slide  the controller.
- ▶ To select **Reset**: turn and press the controller. A prompt appears asking whether you really wish to reset.
- ▶ Select **Yes** or **No**. If you select **Yes** the settings are reset. If you select **No** the process is canceled.

Web browser



Calling up a website

Function restrictions


Internet pages cannot be shown while the vehicle is in motion.

Entering a web address




- ▶ To display the main function bar: slide ↑⊙ the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To select **www**: turn and press the controller. An input menu for the web address is displayed.
- ▶ Enter characters using the controller or the number keypad.
- ▶ To finish entry and call up a website: select  .

Selecting a web address from the list

- ▶ When the character bar is displayed, slide ↑⊙ the controller.
- ▶ To select the desired web address: turn and press the controller. The web address can still be changed as desired.
- ▶ To call up a website: select  . The website is called up.









Navigating the website

Step	Result
▶ Turn the controller.	Navigates from one selectable item (e.g. link, text field or menu) to the next and highlights the respective element on the website.
Sliding the controller:	Moves the pointer on the page.
▶ Left or right ←⊙→	
▶ Up or down ↑⊙↓	
▶ Diagonally ↖⊙↗	
▶ Press the controller.	Opens the selected item.
▶ Press  .	Calls up the menu.

Menu functions




- ① Closes the browser
- ② Goes back/forward
- ③ Refreshes/cancels
- ④ URL entry
- ⑤ Favorites
- ⑥ Disconnects
- ⑦ Options

- ▶ **To show the menu:** press the  button.
- ▶ **To call up the Options menu:** select  by turning and pressing the controller.
- ▶ **To close the website:** select .
- ▶ **To call up the previous website:** select .
- ▶ **To call up the next website:** select .
- ▶ **To refresh the website:** select . The website is refreshed. This procedure may take some time.
- ▶ **To enter a URL:** select .
- ▶ Enter a web address (URL) (▷ page 92).
- ▶ **Favorites:** select .



i While the website is loading, a cross appears in the menu. This can be used to cancel the loading procedure.

Options menu

Opening in a new window





In order to be able to use this function, the cursor must be on a link.



- ▶ **To show the menu:** press the  button.
- ▶ To select : turn and press the controller.
- ▶ Select **Open In A New Window**. The website is opened in a new window.

Adding to bookmarks

Adds the current website to the favorites. The website can then be called up using the menu. You can store up to 20 favorites in the menu.





- ▶ **To show the menu:** press the  button.
- ▶ To select : turn and press the controller.
- ▶ Select **Add to Bookmarks**.
- ▶ Select **Save As Global Bookmark** or **Save As Local Bookmark**. The message: **The website was added to bookmarks** appears.

Current URL

- ▶ **To show the menu:** press the  button.
- ▶ To select : turn and press the controller.
- ▶ Select **Current URL**. The URL appears.



Zoom

You can use this function to enlarge web pages.

- ▶ **To show the menu:** press the  button.
- ▶ To select : turn and press the controller. A menu appears. The • dot indicates the current setting.
- ▶ Select **Zoom**.
- ▶ To navigate on the web page: slide  or  the controller.
- ▶ To zoom in on the web page: turn the controller.



Jumping from link to link

You can use this function to skip from one link to the next on a website.

- ▶ **To show the menu:** press the  button.
- ▶ To select : turn and press the controller. A menu appears. The • dot indicates the current setting.
- ▶ Select [Jump From Link To Link](#). If a website has been called up and the controller is turned, the cursor jumps from link to link.



Directional scrolling

You can use this function to scroll up and down on the web page.

- ▶ **To show the menu:** press the  button.
- ▶ To select : turn and press the controller. A menu appears. The • dot indicates the current setting.
- ▶ Select [Directional Scrolling](#). If a website has been called up and the controller is turned, the cursor moves up or down depending on the direction of the turn.

Settings

Overview

- ▶ **To show the menu:** press the  button.
- ▶ To select : turn and press controller. A menu appears.
- ▶ Select [Settings](#).

You can activate/deactivate the following settings:

- [Download Images Automatically](#)
It may take some time to download the contents of websites that contain a large amount of images. Therefore, it may be useful to deactivate this option.
- [Block Pop-Ups](#)

Pop-ups are windows (usually with advertisements) which are displayed automatically when you call up a website. You can block these displays.

- [Activate Javascript](#)
Javascript makes it possible to display and interact with dynamic content on the website.
- [Allow Cookies](#)
Some websites save information in small text files (cookies) on your system. You can determine whether cookies may be stored.
- [Show Link Target](#)
You can display the link's URL here.
- [Character Size](#)
You can select the font size which is used when displaying the website.
- [Character Code](#)
You can select a different character set here, e.g. if the characters of a website appear distorted.


Changing settings

- ▶ To select the desired setting: turn and press the controller.
Switch the setting on or off .

Changing the character size or character code.

- ▶ Select [Character Size](#) or [Character Code](#).
 - ▶ To select the setting you require: turn and press the controller.
- i** If you change the settings, the websites may not be displayed correctly.

Deleting private data



P82.87-9808-31

- ▶ To display the main function bar: slide ↑⊙ the controller.
 - ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
 - ▶ To show the menu: slide ⊙↓ the controller.
 - ▶ To select **Settings**: slide ⊙↓, turn and press the controller. A menu appears.
 - ▶ To select **Delete Private Data**: turn and press the controller. A menu appears. The ● dot indicates the current setting.
 - ▶ To select the setting you require: turn and press the controller.
- or
- ▶ Select **Delete All Data On Exit**. Switch the setting on or off .

Option	Function
All	Deletes all personal data.
Cache	Deletes data in the cache.
Cookies	Deletes cookies that are created by websites which you have called up.

Option	Function
URL History	Deletes all websites visited (path).
<input checked="" type="checkbox"/> Delete All Data On Exit	If this function is activated <input checked="" type="checkbox"/> , all personal data is deleted when you exit the Internet browser.

i If you reset Audio 20 to the factory settings (reset function), these data and settings are deleted (▷ page 37).

Favorites

Introduction

Favorites/bookmarks are frequently visited websites.

Creating favorites

Adding a favorite in the menu

- ▶ To display the main function bar: slide ↑⊙ the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ Select **www**.
- ▶ Enter the web address (URL) and name using the character bar and press **ok** .

Adding to favorites





- ▶ To call up the menu: press the button.
- ▶ To select : turn and press the controller.
- ▶ Select **Add to Bookmarks** (▷ page 93).

Selecting favorites





- ▶ To display the main function bar: slide ↑⊙ the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.

- ▶ To select the **Internet Favorites** menu: turn and press the controller. The Favorites menu appears.
- ▶ Select the desired bookmark. The favorite is opened in a new window.



Editing favorites

- ▶ To display the main function bar: slide  the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To select the **Internet Favorites** menu: turn and press the controller. The Favorites menu appears.
- ▶ Select the desired favorites.
- ▶ To select : slide  and press the controller.
- ▶ Select **Edit**. An input menu appears.
- ▶ Enter the web address (URL) and name using the character bar.

Deleting favorites

- ▶ To display the main function bar: slide  the controller.
- ▶ To select : turn and press the controller. The menu with the Internet functions is displayed.
- ▶ To select the **Internet Favorites** menu: turn and press the controller. The Favorites menu appears.
- ▶ Select the desired favorites.
- ▶ To select : slide  and press the controller.
- ▶ Select **Delete**. A prompt appears.
- ▶ Select **Yes** or **No**. If you select **Yes** the favorite is deleted. If you select **No** the process is canceled.

Closing the browser

- ▶ Select  in the browser menu (▷ page 92)
- or
- ▶ Press the  button for longer than two seconds. A prompt appears, asking whether you want to close the Internet browser.
 - ▶ Select **Yes** or **No**. If you select **Yes** the application is closed. If you select **No** the process is canceled.


Audio 20 features	98
Switching on the radio	98
Overview	98
Setting the waveband	99
Station	99
Tagging music tracks	101
Displaying the artist and track	102
Calling up sound settings	102
Displaying information	102
Satellite radio	102



Audio 20 features


- i** These operating instructions describe all the standard and optional equipment of your Audio 20 system, as available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions.
- i** Read the information on qualified specialist workshops in the vehicle Operator's Manual.

Switching on the radio

- ▶ Press the  button.
The radio display appears. You will hear the last station played on the last waveband selected.




Switching HD Radio on/off

- ▶ In radio mode: slide  the controller.
- ▶ Select **Options**.
- ▶ By selecting or before **HD Radio**, you determine whether HD radio is switched on or off.

If HD radio is switched off, the system does not switch to digital radio and it is not possible to select any sub-channels.

- i** HD Radio™ and the HD, HD Radio, and “Arc” logos are proprietary trademarks of iBiquity Digital Corp.

Overview





- ① Main function bar
- ② Status bar with compass display
- ③ Main display field with available stations and relevant information
- ④ Display of radio station selected
- ⑤ Radio menu bar

The following functions are available using the radio main function bar:


- **HD Radio FM**: HD FM radio mode
- **HD Radio AM**: HD MW radio mode
- **Sat Radio**: satellite radio
- **Radio Station Presets**: 100 preset positions for radio stations
- **Info on Radio**: information on radio in the Digital Operator's Manual

The following functions are available using the radio menu bar:

- : searches for stations by name
- **Waveband**: selects wavebands
- **Preset**: station preset menu
- **Info**: displays additional information about the current station (radio text)
- : sound settings, Burmester® sound
- **Options**: radio options

Setting the waveband

Button activation



- ▶ In radio mode: press the **RADIO** button. A menu appears with a selection of **HD Radio FM**, **HD Radio AM**, **Radio Station Presets** and **Info on Radio**.
- ▶ To select the desired waveband: turn and press the controller.

Using the main function bar

- ▶ In radio mode: slide **↑** the controller. The radio main function bar and menu bar appear. **Radio** is active.
- ▶ Press the controller. A menu appears with a selection of **HD Radio FM**, **HD Radio AM**, **Radio Station Presets** and **Info on Radio**.
- ▶ To select the desired waveband: turn and press the controller.

Using the menu bar

- ▶ In radio mode: slide **⊙** the controller. The radio menu bar appears.
- ▶ To select **Waveband**: turn and press the controller. A menu appears which allows you to select from **HD Radio FM** and **HD Radio AM**.
- ▶ To select the desired waveband: turn and press the controller.

Station

Selecting a station

From the main display field



All currently available stations are displayed.

- ▶ In radio mode, turn the controller until the desired station is in the center.

Using the current station list



i The station list is available in HD FM radio mode or HD AM radio mode. It includes all stations that can be received.

- ▶ In radio mode, press the controller. The station list appears with the stations currently available.
- ▶ To select the desired station: turn and press the controller.

Using direct entry

- ▶ In radio mode: slide the controller. The radio menu bar appears.
- ▶ To select **Options**: turn and press the controller.
- ▶ Select **Direct Entry**. An additional menu appears.

HD FM radio mode:

- ▶ To select the **HD FM Frequency** option: turn and press the controller.
- ▶ Enter the frequency of the desired station in the entry field.

HD MW radio mode:

- ▶ To select the **HD AM Frequency** option: turn and press the controller.
- ▶ Enter the frequency of the desired station in the entry field.

Satellite radio mode:

- ▶ To select the **SatRadio Channel** option: turn and press the controller.
- ▶ Enter the frequency of the desired station in the entry field.

Station presets:

- ▶ To select the **Radio Station Presets** option: turn and press the controller.
- ▶ Enter the station preset of the desired station.

Using the search function

- ▶ In radio mode: slide the controller. The radio menu bar appears.
- ▶ Select and enter the first letters of the required station using the controller.
- ▶ Press **OK** to confirm. Audio 20 displays a list of available stations.
- ▶ To select stations from the list: turn the controller and press to confirm.


Using the preset position

- ▶ In radio mode: slide the controller.
- ▶ To select **Presets**: turn and press the controller.
- ▶ To select **Enter Preset**: turn and press the controller.
- ▶ Enter the station preset of the desired station.

Station list

- ▶ In radio mode, press the controller. The station list appears with the stations currently available.


Saving/deleting a station



Storing current stations

- ▶ In radio mode: slide the controller. The radio menu bar appears.
 - ▶ To select **Presets**: turn and press the controller.
 - ▶ To select the **Save Current Station/Channel** option: turn and press the controller.
 - ▶ To select the position of the required preset entry: turn and press the controller.
- or
- ▶ Select the **Edit Station Preset** option.
 - ▶ Select the position of the required preset: turn the controller.

This can also be a preset position that is already occupied, which is then overwritten by the current station.



- ▶ Slide  the controller. An additional menu appears.
- ▶ To select the **Save Current Station/Channel** option: turn and press the controller.

The currently set station is stored in the selected preset position. A tone signals a successful preset entry.


or


- ▶ In the main display field, press and hold the controller. A list of current allocated preset positions appears.
- ▶ To select the position of the required preset and confirm: turn the controller and press.

Moving highlighted stations

- ▶ In radio mode: slide  the controller. The radio menu bar appears.
- ▶ To select **Presets**: turn and press the controller.
- ▶ Select **Edit Station Preset**.
- ▶ To select the required preset entry: turn the controller.
- ▶ Slide  the controller. An additional menu appears.
- ▶ To select the **Move Highlighted Station/Channel** option: turn and press the controller. The list of stored stations appears again.
- ▶ To move the highlighted station to the new position: turn the controller and press to confirm.

Deleting highlighted stations

- ▶ In radio mode: slide  the controller. The radio menu bar appears.
- ▶ To select **Presets**: turn and press the controller.
- ▶ Select **Edit Station Preset**.
- ▶ To select the required preset entry: turn the controller.


- ▶ Slide  the controller.
 - ▶ To select the **Delete Highlighted Station/Channel** option in the additional menu: turn and press the controller.
 - ▶ To select **Yes**: turn and press the controller. The highlighted station is deleted.
- or
- ▶ To select **No**: turn and press the controller. The process is canceled.

- i** Frequencies are already stored in Audio 20. There are 100 preset positions available.


Activating/deactivating the station presets display

You can use this function to change to the station presets display.

Activating


- ▶ In radio mode: slide  the controller.
- ▶ To select **Presets**: turn and press the controller.
- ▶ To select **Station Preset View: On**: turn and press the controller. The station preset display appears.
- ▶ To switch between the stored stations: turn the controller.

Deactivating


- ▶ In radio mode: slide  the controller.
- ▶ To select **Presets**: turn and press the controller.
- ▶ To select **Station Preset View: Off**: turn and press the controller. A view of the last waveband you listened to appears.

Tagging music tracks



This function allows you to transfer the music track currently playing to an Apple® device. You can then purchase it in the iTunes® store.

- ▶ In radio mode: slide  the controller. The radio menu bar appears.
- ▶ To select **Options**: turn and press the controller.
- ▶ Select **Tag This Track**. A message appears in Audio 20 about storing track information.

Displaying the artist and track

- ▶ In radio mode: slide  the controller. The radio menu bar appears.
- ▶ To select **Options**: turn and press the controller.
- ▶ You can determine whether or not the artist, track or station name are shown in the main display area with or before **Show Station Information**.

Calling up sound settings


- ▶ In radio mode: slide  the controller. The radio menu bar appears.
- ▶ To select : turn and press the controller. The sound menu appears (▷ page 130).

Displaying information



This function is available in HD FM radio and HD AM radio mode.

Reception is only possible if the radio stations provide the relevant information.

- ▶ In radio mode: slide  the controller.
- ▶ To select **Info**: turn and press the controller. If the station supports this function, additional information will be shown.

If available, you will see:

- station abbreviation
- the current track
- the artist of the current track
- information about the current program
- hotline number for the station or latest headlines

Back to radio display:

- ▶ To select **Info**: slide  and press the controller.

Satellite radio

General notes

Satellite radio mode requires satellite radio equipment and registration with a satellite radio provider.

Note that the categories and channels shown in the illustrations depend on the program content offered by the provider. The illustrations and descriptions in these operating instructions may therefore differ from the channels and categories offered by the provider.

Satellite radio mode may be temporarily unavailable or interrupted for a variety of reasons. These include environmental or topographical conditions as well as other factors beyond the control of Mercedes-Benz USA, LLC. This means operation may not be possible in certain areas.

These include:

- tunnels
- parking garages
- locations inside or next to buildings
- locations in the vicinity of other structures


SIRIUS XM Satellite Radio offers more than 140 digital-quality radio channels providing 100% commercial-free music, sports, news and entertainment.

SIRIUS XM Satellite Radio employs a fleet of high-performance satellites to broadcast around the clock throughout the USA and Canada.

The satellite radio program is available for a monthly fee. Details are available from the SIRIUS XM Service Center and at <http://www.siriusxm.com> (USA) or <http://www.siriusxm.ca> (Canada).

Your new Mercedes-Benz vehicle comes with SIRIUS XM Satellite Radio pre-installed at the factory. This service is free for a six-month trial period. About a month before the trial period ends, information will be provided on how to extend this subscription. An acoustic signal sounds and a message is shown, describing how the subscription can be extended.

Registering satellite radio



- ① Phone number of provider
 - ② SIRIUS XM ID of your satellite receiver
- ▶ Switch on SatRadio mode (▶ page 103). The satellite radio main menu appears showing the preview channel. You cannot select any other stations.

- ▶ To select **Options** in the radio menu bar: turn and press the controller.
- ▶ To select **Service**: turn and press the controller. The service information screen appears.

Once the telephone connection has been established:

- ▶ Follow the instructions of the service staff. The activation process may take up to ten minutes. If the activation is completed successfully, the **Updating Channels...** message appears in the display, followed by the satellite radio main menu.

i You can also have the satellite service activated online. To do so, visit the SIRIUS XM Radio website at <http://www.siriusxm.com> (USA) or <http://www.siriusxm.ca> (Canada).

i If registration is not included when purchasing the system, your credit card details will be required to activate your account.


If the satellite receiver is not installed correctly, the **Device Unavailable** message will appear.

Switching to satellite radio

- ▶ To show the main function bar: slide **↑**⊙ the controller.
- ▶ To select **Radio**: turn and press the controller. The radio display appears. You will hear the last station played on the last waveband selected.
- ▶ To select **Radio** in radio mode: slide **↑**⊙ and press the controller. The menu appears with the available radio modes.
- ▶ To select **Sat Radio**: turn and press the controller.

The **No Service** message appears if there is no signal.

Satellite radio overview



- ① Main function bar
- ② Preset
- ③ Channel name and channel number
- ④ Channel information
- ⑤ Station presets menu
- ⑥ Category list
- ⑦ Keyword search
- ⑧ Options menu

Channel information ④ can be viewed in detail (▷ page 106).

Selecting a category

Satellite radio channels are sorted into various categories. You can choose between various categories such as News/Discussions, Sports and Country (if available). The category list is sorted alphabetically. The content of the categories is sorted by channel numbers.

- ▶ **To call up the category list:** select **Category** in the menu bar by turning and pressing the controller. The category list appears.
- ▶ **To select a category:** turn the controller and press to confirm. The category selected is shown in the display. You hear the station last selected for this category. The ● dot indicates the current setting. The **All Channels** category is at the beginning of the category list. This category enables you to browse all available channels.

Selecting a channel


Channel search

- ▶ When the display/section window is selected, slide ◀⊙ or ⊙▶ the controller. Audio 20 searches in both directions (ascending and descending) and stops at the next channel found in the selected category.

Entering channel numbers directly

- ▶ To select **Options** in the radio menu bar: turn and press the controller. The satellite radio menu appears.
- ▶ To select **Direct Entry**: turn and press the controller. An input menu appears.
- ▶ To select channel numbers: turn and press the controller.
- ▶ Audio 20 sets the selected channel.
- ❗ You can only select currently permitted digits.

Selecting a channel via the satellite radio station list






You can select the channel using the station list displaying the artists and tracks that are currently playing.

- ▶ To select **Options** in the radio menu bar: turn and press the controller.
- ▶ To select **Curr. Station List with Artist & Title**: turn and press the controller.
The channel list appears.
- ▶ Select the desired channel
- ▶ To select **Edit List**: turn and press the controller.
The list of saved channels appears.
- ▶ To select the preset: turn the controller and press for about 2 seconds.
The newly saved station overwrites the existing preset.

i There are 100 presets available.

Keyword search




- ▶ To select the keyword search  in the menu bar: slide  and turn the controller.
- ▶ To enter the required search term: turn and press the controller.
Direct and indirect results are shown.
- ▶ Select the required result.
The relevant channel is played.

Memory functions

Quick save:

- ▶ Set the desired channel in satellite radio mode.
- ▶ Press and hold the controller until the preset list appears.
- ▶ To select the preset number: turn and press the controller.
A tone confirms that the storing process was successful.

Saving a channel using the edit function:

- ▶ In satellite radio mode, slide  the controller.
- ▶ To select **Preset**: turn and press the controller.

Music and sport alerts


General notes

This function makes it possible to store a program alert for your favorite artists, tracks or sporting events.

You can store up to 30 music and sports alerts (favorites).

Music alerts can only be saved whilst a track is being played. You can also specify sport alerts via the menu option. The system then continuously searches through all the channels. If a match is found with a saved message, you will be informed. A window appears with the respective information.

Setting a music alert




- ▶ To select **Options** in the radio menu bar: turn and press the controller.
- ▶ To select **Alert for Artist, Track & Sports Event**: turn and press the controller.
A menu appears.

- ▶ Select **Add New Alert**.
A window with a prompt appears.
- ▶ Select **Artist** or **Track**.
The alert is set for the current artist or track.

The music alert window appears

- ▶ To select **Change To** or **Ignore**: turn and press the controller.
If you select **Change To**, the channel is changed and the favorite artist or track is played.
If you select **Ignore**, the current channel will continue playing.

Setting a sport alert



- ▶ To select **Options** in the radio menu bar: turn and press the controller.
- ▶ To select **Alert for Artist, Track & Sports Event**: turn and press the controller.
A menu appears.
- ▶ Select **Manage Sports Alerts**.
A menu appears.
- ▶ Select **Select New Alerts**.
A menu appears.
- ▶ Select the desired team from a league, e.g. college, NBA, NHL, NFL or MLB.
The alert function for the sports team is added.

Editing music and sport alerts

- ▶ Select **Edit Alert**.
A list of set sport alerts appears.
- ▶ Select **Manage Music Alerts**.
A list of set artists and tracks (artist) appears.

Tagging music tracks

This function allows you to transfer the music track currently playing to an Apple® device. You can then purchase it in the iTunes® store. Not all radio stations support this function.

- ▶ To select **Options** in the radio menu bar: turn and press the controller.
- ▶ To select **Tag This Track**: turn and press the controller.
A message about saving this music track on the Apple® device appears.


Displaying information



- ▶ To select **Info** in the radio menu bar: turn and press the controller.
Information on the currently received program is displayed.



If available, you will see:

- the channel logo
- the channel abbreviation
- the artist of the track that is currently being played
- the current track

- ▶ **To return to the radio display:** select **Info** by sliding  and pressing the controller.

Displaying service information

The provider's customer service center is available by phone at any time to answer any general questions or questions on the versions available.

- ▶ To select **Options** in the menu bar: slide  and press the controller.
- ▶ To select **Service**: turn and press the controller.
The provider's details appear.
- ▶ **To return to the main display:** press the  button.

Channel list updates

During reception of a new channel list, the **Updating Channels...** message is shown. The station last selected is switched to mute until the update has been completed. Satellite radio mode is not available during this process.

Once the update has been completed, the satellite radio basic menu appears. If the channel previously selected is still available, this channel will be played.

Sound settings

Information on sound settings (> page 130).

Audio 20 features	110
Activating media mode	110
Audio mode	111
Media search	116
Bluetooth® audio mode	118
Operation with the Media Inter- face	124
Picture viewer	126

Audio 20 features

- i** These operating instructions describe all the standard and optional equipment of your Audio 20 system, as available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions.
- i** Read the information on qualified specialist workshops in the vehicle Operator's Manual.

Activating media mode

General notes

There are several ways to activate media sources using Audio 20.

The relevant sections of the Operator's Manual describe the simplest way to activate a media source. This section describes all options for activating media sources. If you wish to play external media sources, the default display must already be turned on.

The following external media sources can be used:

- Apple® devices (e.g. iPhone®)
- USB devices (e.g. USB stick, MP3 player)
- CD
- SD memory cards
- via devices connected by Bluetooth®

Button activation

- ▶ To call up the media menu: press the **MEDIA** button.
The last media source you have set is displayed.
- ▶ Press the **MEDIA** button again.
The menu appears with the available media sources.
- ▶ To select the media source: turn the controller and press to confirm.
Depending on the vehicle equipment, the following media sources will be available:
 - Disc
 - Memory Card
 - Media Interface 1
 - Media Interface 2
 - Bluetooth Audio
 If playable media files are found, they will be played by Audio 20.

Using the main function bar



- ▶ To display the main function bar: slide **↑** the controller.
- ▶ To select **Media**: turn and press the controller.
The last media source you have set is displayed.

- ▶ To select **Media** in media mode: slide \uparrow \odot and press the controller. The menu appears with the available media sources.
- ▶ To select the media source: turn the controller and press to confirm. If the media source contains music files, these will be played. The corresponding basic menu will be shown.

Using the device list



- ▶ In media mode, slide \odot \downarrow the controller. The media menu bar is shown.
- ▶ To select **Devices**: turn and press the controller. The available media sources will be shown. The • dot indicates the current setting.
- ▶ Select the media source. If the media source contains music files, these will be played. The corresponding basic menu will be shown.

Switching on automatically

After inserting a CD, this media mode is automatically switched on by Audio 20.

If playable media files are found, they will be played by Audio 20.

If a media function is already switched on in Audio 20, this will be interrupted and the basic display of the CD mode will appear. If another function, such as navigation, is being operated, the basic display will not change.

Only the music from the last inserted CD will be played.

Audio mode

Important safety notes

WARNING

The CD drive is a class 1 laser product. If you open the housing of the CD drive, there is a risk of exposure to invisible laser radiation. This laser radiation could damage your retina. There is a risk of injury.

Never open the housing. Always have maintenance and repair work carried out at a qualified specialist workshop.

WARNING

Handling discs while driving may distract you from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident.

Handle discs only when the vehicle is stationary.

Notes on audio mode

Permissible data carriers

- CD-R, CD-A and CD-RW
- SD memory card
- USB storage device

Permissible file systems

- ISO 9660/Joliet standard for CDs
- FAT16, FAT32, exFAT and NTFS for SD memory card and USB storage media

Multisession CDs

For multisession CDs, the content of the first session determines how Audio 20 will process the CD. Audio 20 plays only one session and gives priority to the audio CD session.

File structure of a data carrier

When you create a disc with compressed music files, the tracks can be organized in folders. A folder may also contain subfolders. The disc may contain no more than eight directory levels. Files beyond the eighth level will not be recognized by the system.

- **i** Audio 20 supports up to 15,000 files from one data medium. For data media with more than 64 GB, only files in the following folders are supported: Music, Pictures.

Track and file names

When you create a disc with compressed music files, you can assign names to the tracks and folders.

If MP3 or WMA files are stored in the root directory itself, the root directory will also be treated as a folder.

You should observe the following when assigning track names:

- track names must have at least one character.
- track names must have an extension of a supported audio format, e.g. mp3 or aac.
- there must be a dot between the track name and the extension.

Example of a correct track name:
"Track 1.mp3".

Permissible formats

Audio 20 supports the following audio formats:

- MP3
- WMA
- CD-A
- AAC formats: .aac, .mp4, .m4a and .m4b

Copy-protected iTunes® music files with the .m4p file extension are not supported.

Permissible bit and sampling rates

Audio 20 supports the following types of MP3 files:

- fixed and variable bit rates from 32 kbit/s to 320 kbit/s
- sampling rates of 8 kHz to 48 kHz

Audio 20 supports the following types of WMA files:

- fixed bit rates from 5 kbit/s to 384 kbit/s
- sampling rates of 8 kHz to 48 kHz

Audio 20 does not support the following types of WMA files:

- DRM (Digital Rights Management) encrypted files
- variable bit rate
- WMA Pro
- 5.1 surround sound

- **i** Only use tracks with a bit rate of at least 128 kbit/s and a sampling rate of at least 44.1 kHz. Lower rates can cause a noticeable deterioration in quality. This is especially the case if you have activated a surround sound function.

Selecting an active partition (USB mass storage devices only)

You can select this function for USB storage devices when the storage device is partitioned. Up to 9 partitions (primary or logical, FAT, FAT32 and NTFS) are supported.

Selecting an active partition

- ▶ To select **Options** in the media menu bar: turn and press the controller.
- ▶ Select **Select Active Partition**.

Notes on copyright

Audio files that you create or reproduce yourself for playback are generally subject to copyright protection.

In many countries, reproductions, even for private use, are not permitted without the prior consent of the copyright holder.

Make sure that you know about the applicable copyright regulations and that you comply with these.

Notes on compact discs

! Please bear the following in mind:

- Do not affix stickers or labels to the discs.
- CDs must not be thicker than 1.3 mm.
- CDs must be round with a diameter of 12 cm. Do not use an adapter.

Discs with copy protection are not compatible with the audio CD standard. Consequently, it may not be possible to play them on the Audio 20 system.

Playback problems may occur when playing copied discs.


There may be playback problems if you play CDs that you have copied yourself with a storage capacity of more than 700 MB.

i Audio 20 is able to play back audio CDs in multichannel audio format.


Inserting and removing a CD from the single CD drive

Before inserting a CD, ensure that the cup holder is empty.


Before removing a disc, be aware that the CD can become hot.

- ▶ **To insert:** press the  button on the single drive.
If there is a disc already inserted, it will be ejected.
- ▶ Insert a disc into the disc slot with the printed side facing upwards.
The drive closes and the disc is played.
If the CD is operated in Media mode, the corresponding basic menu will be shown. If the CD is started using another application (e.g. navigation) the display will not change.

i The drive may not be able to play discs with copy protection.

- ▶ **To remove:** press the  button.
The drive ejects the disc.
- ▶ Remove the ejected disc from the slot.
If you do not take the disc out of the slot, it is drawn in again automatically after a short while.

Menu overview



- ① Main function bar
- ② Media menu bar
- ③ Track display on the disc
- ④ Track number and number of tracks in the track list
- ⑤ Artist and album
- ⑥ Numerical time display
- ⑦ Graphic time display
- ⑧ Cover view (if available)

Inserting and ejecting an SD memory card

Important safety notes

WARNING

SD memory cards are small parts. They can be swallowed and cause asphyxiation. This poses an increased risk of injury or even fatal injury.

Keep SD memory cards out of the reach of children. If an SD memory card is swallowed, seek immediate medical attention.

! If you are no longer using the SD memory card, you should remove it and take it out of

the vehicle. High temperatures can damage the card.

Audio 20 supports SD memory cards (**Secure Digital**), SDHC memory cards (**Secure Digital High Capacity**), and SDXC memory cards (**Secure Digital eXtended Capacity**).

Inserting an SD memory card

- ▶ Insert the SD memory card into the multimedia connector unit until it engages. The side with the contacts must face downwards.
- If the memory card has been selected as a media source, the medium is played and the files are loaded in the background. If there are no supported audio files, you will see a message to this effect.
- ▶ Select the media source (▷ page 110).

Ejecting an SD memory card

- ▶ Press the memory card.
The memory card is ejected.
- ▶ Remove the memory card.

Connecting USB devices

There are two USB ports in the stowage space under the armrest.

- ▶ Connect the USB device to the USB port. If the corresponding media display is visible, the medium is played and the files are loaded in the background. If there are no supported audio files, you will see a message to this effect.

i MP3 players must support Media Transfer Protocol (MTP).

Activating media mode

Switching on automatically

After inserting a CD or an SD memory card, the media mode is automatically switched on by Audio 20.

If playable media files are found, they will be played by Audio 20.

If a media function is already switched on in Audio 20, this will be interrupted and the basic display of the CD mode will appear. If another function, such as navigation, is being operated, the basic display will not change. Only the music from the last inserted CD will be played.


Depending on the vehicle equipment, the default display must already be turned on when using with USB devices.


- ▶ Insert CDs: (▷ page 113)
- or
- ▶ Insert an SD memory card: (▷ page 114)
- or
- ▶ Connect a USB device: (▷ page 114)
Audio 20 loads the inserted medium and playback starts automatically.

Further options for switching on

- Using the main function bar: (▷ page 110)
- Using the device list: (▷ page 111)
- Using the **MEDIA** button: (▷ page 110)


Playback options

- ▶ In media mode, slide  the controller. The media menu bar is shown.
- ▶ To select **Options**: turn and press the controller.



Play mode

- ▶ To select **Playback Mode**: turn and press the controller.
- ▶ Select **Normal Track Sequence**.
The current track list is played in the order it appears on the data medium.
- ▶ Select **Random Track List**.
The current track list is played in random order.
- ▶ Select **Random Medium**.
All tracks on the data medium are played in random order.



Direct track entry

- ▶ To select **Track Number::**: turn and press the controller.
A menu appears.
- ▶ Enter the desired track number.

Skip to time

- ▶ To select **Skip to Time**: turn and press the controller.
A menu appears.
- ▶ To set the time: turn the controller
or
- ▶ Set the desired time.

Selecting an active partition

- ▶ To select **Select Active Partition**: turn and press the controller.
With the **Select Active Partition** option, you can select a partition in the USB data medium.

Showing track information

- ▶ To select **Show Track Information**: turn and press the controller.
Checking or unchecking the box in front of **Show Track Information** displays or hides the information on the track, artist and album in the main display field.

Pause and playback function

- ▶ **To pause playback**: in audio mode, slide the controller.
The media menu bar is shown.
- ▶ To activate in the Media menu bar: turn and press the controller.
Playback is interrupted here. The display changes to .
- ▶ **To continue playback**: in audio mode, slide the controller.
The media menu bar is shown.
- ▶ To activate in the Media menu bar: turn and press the controller.
Playback is continued from the point of interruption. The symbol changes to .

Selecting a track


Selecting using the current track list

- ▶ **To display the current track list**: press the controller in the basic display.
The category list appears.
- ▶ Select the current track list.
- ▶ To select a track: turn the controller and press to confirm.


Selecting by skipping to a track

- ▶ To skip forwards or backwards to a track: turn or briefly slide or the controller in the media basic display.

Search menu

- ▶ In media mode, slide  the controller. The media menu bar is shown.
- ▶ To select **Search**: turn and press the controller. The category list is shown.
- ▶ Select a category, e.g. **Genres**. Sub-categories appear with the selection of the main category (depends on the Audio 20 default settings and the music tracks available).

Media



- ▶ Select a sub-category, e.g. **Rock**. If the **Rock** sub-category includes music tracks, these will be shown.

Media search

General notes

Audio 20 plays back files from the following data mediums:

- Disc (audio CD)
- Memory card
- USB storage device
- Apple® devices (folder, year and photos are not available)

The categories are displayed according to the data available.


Starting the media search

- ▶ In media mode, slide  the controller.

The media menu bar is shown.

- ▶ To select **Search**: turn and press the controller. The category list appears.

Category list

- ▶ In media mode, slide  the controller. The media menu bar is shown.
- ▶ To select **Search**: turn and press the controller. The category list is shown.

Depending on the connected media sources and files, the following categories are listed:

- **Current Track List**
- **Folder**
- **Select By Cover**
- **Keyword Search**
- **Playlists**
- **Artists**
- **Albums**
- **Track**
- **Genres**
- **Year**
- **Composers**
- **Photos**
- **Podcasts**
- **Audiobücher (Audiobooks)**

- i** The categories are available as soon as the entire media content has been read and analyzed.

If the same device is reconnected with unchanged media content, these categories are available more quickly.

When connecting Apple® devices, the categories “Folder”, “Year” and “Photos” are not available.

Searching by current track list



P82.89-0358-31


- ▶ To select **Current Track List** in the category list: turn and press the controller. The selection list appears.
- ▶ Select the required track.

Searching by folder

Playable files can be searched for in the active data medium's directories.

- ▶ To select **Folder** in the category list: turn and press the controller. The folder list appears.
- ▶ Select the required folder. The track list appears.
- ▶ Select the required track.

Selecting by cover




P82.89-0239-31

- ▶ To select **Select By Cover** in the category list: turn and press the controller. A menu with cover views appears.


Audio 20 searches all media sources.

- ▶ To move the desired folder to the front: turn the controller. The track list appears.
- ▶ To select the desired track: turn and press the controller.


Searching by genre



P82.89-0364-31


- ▶ To select **Genres** in the category list: turn and press the controller. Audio 20 searches all media sources. A selection list with **Genres** and media sources appears.
- ▶ Select the desired **Genres**. A selection list with music tracks from the selected genre appears.
- ▶ Select a music track. The track is played. The basic menu for the active media source is shown.
- ▶ To exit the selection list: press the  button.

Keyword search



P82.89-0360-31

- ▶ To select **Keyword Search** in the category list: turn and press the controller. The input field appears.
- ▶ To select the desired characters: turn and press the controller for each character. Entering just part of the name of a track or artist is enough. The search result then displays the entire text.



- ▶ Select . The search results are displayed. The numbers behind the results, as shown in the example **Artists** (1/1), mean: 1 result that contains the exact keyword searched for and 1 result that is similar.
- ▶ Select one of the results. Keywords that have already been searched for are displayed in the "Search history" without having to enter them completely. They can be accepted directly and displayed in the search result.
- ▶ Select an entry. Albums and covers (if available) are shown. Audio 20 searches all media sources.
- ▶ Select an album. The tracks are listed.



- ▶ Select a track. The basic display appears and playback starts.

Bluetooth® audio mode

Connecting Bluetooth® audio devices

Prerequisites

- ▶ Activate the Bluetooth® function in Audio 20 (▶ page 34).

Bluetooth® audio mode requires a Bluetooth®-capable audio device.

Check your Bluetooth® audio device for the following (see the manufacturer's operating instructions):

- Bluetooth® audio profile
 - The Bluetooth® audio device must support the A2DP and AVRCP Bluetooth® audio profiles.
- Bluetooth® visibility
 - Certain Bluetooth® audio devices do not just require activation of the Bluetooth® function. In addition, your device must be made "visible" to other devices.
- Bluetooth® device name
 - This device name is predetermined but can usually be changed. For a clear selection of the Bluetooth® device, Mercedes-Benz recommends that you customize the device name.
- ❗ A2DP (**A**dvanced **A**udio **D**istribution **P**rofile): Bluetooth® audio profile for audio data transmission
- AVRCP (**A**udio **V**ideo **R**emote **C**ontrol **P**rofile): Bluetooth® audio profile for audio data playback.
- ❗ The Bluetooth® device must be visible for authorization. After authorization, Audio 20 finds the Bluetooth® device even when it is not visible.

- ▶ The Bluetooth® function in Audio 20 must be activated (▷ page 34).

General notes

Before using your Bluetooth® audio device with Audio 20 for the first time, you will need to authorize it.

When you authorize a new Bluetooth® audio device, it is connected automatically. Connection involves first searching for a Bluetooth® audio device and then authorizing it.

You can authorize up to fifteen Bluetooth® devices.

- ❗ If you authorize a mobile phone that supports Bluetooth® audio, the A2DP and AVRCP Bluetooth® audio profiles are connected automatically.

The mobile phone is then entered:

- in the Bluetooth® telephone list (▷ page 61)
- in the Bluetooth® device list (▷ page 119)


Mercedes-Benz recommends authorizing a mobile phone in Bluetooth® telephony (▷ page 62).

- ❗ If the mobile phone that is connected only supports two Bluetooth® profiles at the same time, Audio 20 functions may behave as follows:
 - when connecting to the Internet, playback is stopped on the Bluetooth® audio device.
 - when starting playback on the Bluetooth® audio device, the Internet connection is ended.

Searching for and authorizing a Bluetooth® audio device

Switching to Bluetooth® audio mode

- ▶ To call up the media menu: press the **MEDIA** button.
The last media source you have set is displayed.
- ▶ To display the main function bar: slide **↑** the controller.
- ▶ To select **Media**: turn and press the controller.
- ▶ To select **Bluetooth Audio**: turn and press the controller.
A menu appears.
If you see the **No Bluetooth Audio Device Connected** message, you will need to authorize the Bluetooth® audio device first.
- ▶ To select **Options** in the Bluetooth audio menu: slide **⊙↓** the controller and press to confirm.
- ▶ To select **Bluetooth Audio Devices**: press the controller.
A new menu appears.



- ① Bluetooth® audio player within range and already authorized
- ② Newly detected mobile phone with Bluetooth® audio mode in range

The Bluetooth® device list displays all authorized devices, whether they are within range or not. After a device search, devices which are within range but not authorized are also displayed.

Searching for Bluetooth® audio

- ▶ To select **Search for Audio Devices**: press the controller. A message appears.
- ▶ Select **Start Search**.
Audio 20 searches for Bluetooth® audio devices within range and adds them to the Bluetooth® device list.
The duration of the search depends on the number of Bluetooth® audio devices within range and their characteristics.

i On some Bluetooth® audio devices, playback has to be started on the device itself first so that Audio 20 can play the audio files. Bluetooth® must also be given as a media output location for the audio device used.

Authorizing Bluetooth® audio

- ▶ Select a Bluetooth® audio device that has not yet been authorized from the list: turn and press the controller. Authorization starts.
Depending on the Bluetooth® audio device used, you now have two options for continuing with authorization.

Option 1: entering the passkey

- ▶ You can find information on this in the "Authorizing (connecting) a mobile phone" section (▷ page 62).
After successful authorization, the Bluetooth® audio device is connected and starts playing.

Option 2: Secure Simple Pairing

- ▶ You can find information on this in the "Authorizing (connecting) a mobile phone" section (▷ page 62).
After successful authorization, the Bluetooth® audio device is connected and starts playing.
- i** The Bluetooth® audio device must support Bluetooth® version 2.1 for connection via Secure Simple Pairing. Audio 20 creates a six-digit code, which is displayed simul-

taneously on both devices that are to be connected.

For some Bluetooth® audio devices, the pairing must be confirmed within 10 seconds.

- ▶ If the number code displayed on Audio 20 and on the Bluetooth® audio device is the same, select **Yes**: press the controller. If you select **Yes**, authorization continues and the Bluetooth® audio device is connected. Playback starts.
If you select **No**, authorization will be canceled.

External authorization

If Audio 20 does not find your Bluetooth® audio device, this may be due to particular security settings on your Bluetooth® audio device. In this case, check whether conversely your Bluetooth® audio device can locate the Audio 20 system.

The Bluetooth® device name for Audio 20 is **MB Bluetooth**.

- ▶ Switch on Bluetooth® audio mode (▷ page 122).
- ▶ To select **Options**: slide **⊙↓** and press the controller.
- ▶ To select **Bluetooth Audio Devices**: press the controller.
- ▶ To select **Connect via Audio Device**: turn and press the controller.

Authorizing

- ▶ Start the authorization on your Bluetooth® audio device (see the manufacturer's operating instructions).
After successful authorization, the Bluetooth® audio device is connected and starts playing.

On some Bluetooth® audio devices, playback has to be started on the device itself first so that Audio 20 can play the audio files.

Device-specific information on authorizing and connecting Bluetooth®-capable mobile phones can be found on the Internet at <http://www.mercedes-benz.com/connect>.

Reconnecting a Bluetooth® audio device

The Bluetooth® audio profiles are connected automatically under the following circumstances:

- one of the last two mobile phones to have been connected has also been used as a Bluetooth® audio player (if this function is supported by the mobile phone).
- the mobile phone is automatically connected. The Bluetooth® audio profiles are then also connected.

i For an automatic connection with Audio 20, the telephone must be within range.


For most Bluetooth® audio devices, the "automatic connection" must be activated by ticking a box. Depending on the device used, this prompt often takes place when authorizing (see the manufacturer's operating instructions).

If the **No Bluetooth Audio Device Connected** message appears, you have two options to reconnect the Bluetooth® audio device.

Option 1:

- ▶ In the **Connect Device** basic display: press the controller.
If Audio 20 can locate the Bluetooth® audio device, it will be connected and playback will start.

Option 2:


- ▶ To select **Options**: slide  and press the controller.
- ▶ To select **Bluetooth Audio Devices**: press the controller.
- ▶ To select a Bluetooth® audio device: turn and press the controller.
If the Bluetooth® audio device has been authorized, playback starts.

Bluetooth® audio device and simultaneous search for mobile phones

i When searching for a mobile phone or a new Bluetooth® audio device, the connection to an already activated Bluetooth® audio device is stopped.

In the Bluetooth® audio basic display, you will see the **No Bluetooth Audio Device Connected** message, and the **Connect Device** menu item cannot be selected.

Displaying details


- ▶ To select a Bluetooth® audio device from the Bluetooth® device list: turn the controller.
- ▶ To select the symbol to the right of the Bluetooth® audio device: slide  the controller.
- ▶ To select **Details**: turn and press the controller.

The following information concerning the selected mobile phone is shown:

- Bluetooth® name
- Bluetooth® address
- availability status (shown after an update)
- authorization status

- ▶ **To close the detailed display**: press the  button.

De-authorizing (deregistering) a Bluetooth® audio device



- ▶ To select a Bluetooth® audio device from the Bluetooth® device list: turn the controller.
 - ▶ To select the symbol to the right of the Bluetooth® audio device: slide  and press the controller.
 - ▶ To select **Deauthorize**: press the controller. A prompt appears asking whether you really wish to deauthorize this device.
 - ▶ To select **Yes** or **No**: turn and press the controller. If you select **Yes**, the device will be deleted from the Bluetooth® device list. If you select **No** the process is canceled.
- i** Before re-authorizing the Bluetooth® audio device, you should also delete the device name **MB Bluetooth** from your Bluetooth® audio device's Bluetooth® list (see the Bluetooth® audio device's operating instructions).

Switching to Bluetooth® audio mode

Basic display





- ① Audio transmission status (depending on the Bluetooth® audio device, also title name and artist)
- ② Data medium position in the media list
- ③ Sound settings
- ④ Device list

- ⑤ To stop  or start  playback
- ⑥ Name of the connected Bluetooth® audio device (example)
- ⑦ Options menu







Some mobile phones only support two Bluetooth® profiles at the same time (e.g. Hands-Free Profile for Bluetooth® telephony and Bluetooth® audio profile for audio streaming). If you activate Bluetooth® audio mode and there is already an active Internet connection, this can cause the connection to be terminated.

Switching to Bluetooth® Audio

- ▶ To call up the media menu: press the  button. The last media source you have set is displayed.
- ▶ To show the main function bar: slide  the controller.
- ▶ To select **Media**: turn and press the controller.
- ▶ To select **Bluetooth Audio**: turn and press the controller. Audio 20 activates the Bluetooth® audio device. The basic display then appears. Playback starts.

i If the Bluetooth® audio device connected supports metadata and corresponding data is available, then the artist, track and album name can be displayed.


Starting/stopping playback

- ▶ To select **Start playback** : turn and press the controller. Playback starts.  is selected.
- ▶ **To stop playback**: select . A message appears.  is selected.
- ▶ **To continue playback**: select . A message appears.  is selected.

Starting playback if the Bluetooth® audio device has been stopped

During the search for mobile phones (> page 61), the connection with the Bluetooth® audio device is terminated. In the Bluetooth® audio basic display (> page 122) you will see the **No Bluetooth Audio Device Connected** message and the **Connect Last Used Player** menu item cannot be selected.

When the search is finished, the Bluetooth® audio device can be reconnected.



▶ To select **Start playback**: : slide and press the controller. Playback resumes from the beginning.

▶ To select **Connect Last Used Player**: press the controller. Depending on the Bluetooth® audio device used, playback starts immediately or you must start playback manually.

In this case, you will see the **Bluetooth Audio Device Paused** message.

i If there is an Internet connection and the mobile phone that is connected only supports two Bluetooth® profiles at the same time, the Internet connection is interrupted.

i The connection to the Bluetooth® audio device can also be interrupted if:

- the connected mobile phone only supports 2 Bluetooth® profiles at the same time.
- you connect to the Internet using Audio 20 (> page 85).

Selecting a track

The function is not supported by all Bluetooth® audio devices.

Some mobile phones impair function with regard to the following criteria:

- the number of tracks that can be selected
- the time period until the next or previous track is played

▶ Switch the multifunction steering wheel to the media menu (see the vehicle Operator's Manual).

▶ **To skip forwards or backwards to a track**: press the or button on the multifunction steering wheel.

▶ **Rapid scroll**: press and hold the or button on the multifunction steering wheel until the desired track is reached. If you press and hold the or buttons, the rapid scrolling speed increases after a short time.

i In rapid scroll, track names are not shown, but instead only Track 1, Track 2 etc. The playback times for the tracks played are not displayed. This is available as an optional function starting with AVRCP Version 1.3. There is also no music search option available with Bluetooth® Audio.

Selecting playback options

If the Bluetooth® audio device supports the corresponding function, the following options are available:

- **Normal Track Sequence:** the tracks are played in the normal order (e.g. track 1, 2, 3 etc.).

Audio data playback is determined by the order in which the tracks are written to the data medium. Alphabetical order is the most common. Once all the tracks in a folder have been played, the tracks in the next folder are played.


- **Random Track List:** the current track list is played in random order (e.g. 3, 8, 5 etc.).
- **Random Medium:** all tracks on the data medium are played in random order (e.g. track 3, 8, 5 etc.).

Playback options are optional functions and are not, or only partially, supported by Bluetooth® audio devices.

Selecting playback options

- ▶ To select **Options:** turn and press the controller.
- ▶ Select **Playback Mode.**
A ● dot indicates the current setting.
- ▶ Select the desired option.
If you select **Random Track List**, you will see a corresponding message in the display or selection window.

Increasing the Audio 20 volume

- ▶ To select **Options:** slide  and press the controller.
- ▶ To select **Volume:** turn and press the controller.
A menu appears. The ● dot indicates the current setting.
- ▶ Select **Standard** or **Boost.**
Information on sound settings (▷ page 130).


Operation with the Media Interface

General notes

Media Interface is a universal interface for the connection of mobile audio devices. Media Interface in Audio 20 has two USB connections.

The USB connection sockets are located in the stowage compartment under the armrest.

Media Interface basic display



- ① Main function bar
- ② Media menu bar
- ③ Track display on the disc
- ④ Track number and number of tracks in the track list
- ⑤ Numerical time display
- ⑥ Graphic time display
- ⑦ Cover view (if available)

Switching to Media Interface

- ▶ Connect a data medium to USB socket 1 or USB socket 2 (▷ page 114).
- ▶ Select the basic menu for Media Interface 1 or Media Interface 2 (▷ page 111).
If playable media files are found, they will be played by Audio 20.
If you remove a device, the **No Device Connected** message appears.

Supported devices

The Media Interface allows you to connect the following devices to Audio 20:

- iPod®
- iPhone®
- iPad®
- MP3
- USB devices

i It is not possible to run two Apple® devices simultaneously. Therefore the device last connected is loaded.

i iPod®, iPhone® and iPad® are registered trademarks of Apple Inc., Cupertino, California, USA.

i Audio and picture files can be played back. Picture files from Apple® devices and MP3 players cannot be displayed (except cover pictures).

For details and a list of supported devices, visit our website at

<http://www.mercedes-benz-mobile.com/>. Then follow the instructions in the "Media Interface" section.

Or call the Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCEdes (1-800-367-6372) (for the USA) or Customer Relations at 1-800-387-0100 (for Canada).

Supported data formats

Music	mp3, wma, aac
Images	jpg, jpeg, bmp, png

Selecting a music file

Selecting with the controller

- ▶ **To display the current track list:** press the controller in the basic display. The track list for the active data medium appears.
- ▶ To select a track: turn the controller and press to confirm.
- ▶ **To skip forwards or backwards to a track:** turn the controller in the basic display. The selected track is played.

Fast forward/rewind

- ▶ With the media source active in the basic display, slide ◀⊙ or ⊙▶ the controller and hold it until the desired position has been reached.

Search function

Selecting Search using media menu bar

- ▶ Slide ⊙↓ the controller. The media menu bar is shown.
- ▶ To select **Search**: turn and press the controller. The category list appears.

Overview

The following categories are listed:

- [Current Track List](#)
- [Folder](#)
- [Select By Cover](#)
- [Keyword Search](#)
- [Playlists](#)
- [Artists](#)
- [Albums](#)
- [Track](#)
- [Genres](#)
- [Year](#)

- Composers
- Photos
- Podcasts
- Audiobücher (Audiobooks)

i The functions are available as soon as the entire media content has been read and analyzed.

If the same device is reconnected with unchanged media content, these functions are available more quickly.


The audio books and podcasts categories are not available for USB devices.

When connecting Apple® devices, the categories “Folder”, “Year” and “Photos” are not available.



- ▶ To select a category, e.g. **Current Track List**: turn and press the controller. The selection list appears.
- ▶ Select the required track.
- ▶ **Keyword search**: using the controller, enter the characters for the desired search term and confirm (▶ page 117). Search results are sorted according to the available categories, displayed and can then be selected.

Playback options



- ▶ In media mode, slide Ⓢ the controller. The media menu bar is shown.
- ▶ To select **Options**: turn and press the controller.
- ▶ To select the desired playback option: turn and press the controller.

Picture viewer

General notes

If there are pictures on the active data medium, you can view them on the Audio 20 display.

The following data media and picture formats are supported:

- **Data media**: CD, USB devices, SD memory cards
- **Picture formats**: jpeg, jpg, bmp, png

The maximum image resolution is 20 megapixels

It is not possible to view a picture while the vehicle is in motion.


Displaying pictures


- ▶ In media mode, slide Ⓢ the controller.

The media menu bar is shown.

- ▶ To select **Search**: turn and press the controller. The category list appears.
- ▶ To select **Photos**: turn and press the controller. A directory list appears. Folders and picture files can be shown.
- ▶ Select a folder or picture. If there is no picture on the data medium, an empty list is shown. You can search for pictures on other data media.

Searching for pictures on other data media

- ▶ In the directory list, slide  the controller. The device list appears.



Example: the directory list displays the existing picture files


- ▶ To select a data medium with picture files: turn the controller and press to confirm. A directory list appears. Folders and picture files can be shown.
- ▶ Select a folder or picture.






Starting a slide show

- ▶ While viewing a picture, press the controller. The image menu appears.
- ▶ To select **Start Slideshow**: turn and press the controller. The slide show starts.

- ▶ To end the slide show: press the controller. The image menu appears.
- ▶ Select **End Slide Show**.

Changing the picture view



- ▶ Press the controller. The image menu appears.
 - ▶ To select **Turn Clockwise**: turn and press the controller. The picture rotates 90 degrees.
 - ▶ Select **Turn Counterclockwise**. The picture rotates 90 degrees.
 - ▶ Select **Zoom In**. The size of the picture increases. After you have zoomed into the picture, you can move the section of the picture.
 - ▶ To move the section of the picture: slide  and  and  and  the controller.
 - ▶ To revert to the original size: press the controller
- or
- ▶ Press the  button.

Closing the picture viewer

- ▶ Press the controller. The menu appears.
- ▶ To select **Close Picture Viewer**: turn and press the controller. Audio 20 returns to the last accessed media function.

Audio 20 features	130
Sound settings	130
Burmester® surround sound system	131





Audio 20 features

- i** These operating instructions describe all the standard and optional equipment of your Audio 20 system, as available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions.
- i** Read the information on qualified specialist workshops in the vehicle Operator's Manual.

Sound settings

Calling up the sound menu

The sound settings can be selected to suit a variety of different audio sources. This means that it is possible to set more bass for radio mode than for USB mode, for example. The respective sound menu can be called up from the menu of the desired mode.






- ▶ Switch to radio mode (▷ page 98).
- or
- ▶ Switch to media mode (▷ page 110).
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select : turn and press the controller.
The menu appears with the last setting accessed, e.g. **Equalizer**.

Sound menu overview


Function	Options
Equalizer	Sets treble, mid-range and base
Balance/fader	Moves the sound focus: left/right and front/rear

Setting treble, mid-range and bass









- ▶ Call up the sound menu (▷ page 130).
- ▶ Turn the controller until **Equalizer** is brought to the front.
- ▶ To activate rotary menus for treble, mid-range and base: slide  the controller.
- ▶ To switch between the rotary menus: slide  or  the controller.
- ▶ To make the desired **Equalizer** settings: turn the controller.
Rotary menus show the set values.
- ▶ To return to the menu: slide  the controller.
- ▶ To return to the basic menu: press the  button briefly.

Adjusting the balance/fader



Balance moves the focus of the sound between left and right.

Fader moves the focus of the sound between front and rear.

- ▶ Call up the sound menu (▷ page 130).
- ▶ Turn the controller until **Balance/Fader** is brought to the front and then slide  the controller.
- ▶ To activate the menu for balance and fader: press the controller.
- ▶ To adjust the balance focus: slide  or  the controller.
- ▶ To adjust the fader focus: slide  or  the controller.
An image shows the sound focus set.
- ▶ To exit the menu: press the  button.

Burmester® surround sound system



General notes

The Burmester® surround sound system has a total output of 590 watts and is equipped with 13 loudspeakers.

The Burmester® surround sound system is available for all functions in the radio and media modes.

Calling up the sound menu

The sound settings can be selected to suit a variety of different audio sources. This means that it is possible to set more bass for radio mode than for USB mode, for example. The respective sound menu is called up from the menu of the desired mode.






- ▶ Switch to radio mode (▷ page 98).
- or
- ▶ Switch to media mode (▷ page 110).
- ▶ To switch to the menu bar: slide  the controller.
- ▶ To select : turn and press the controller.
The menu appears with the last setting accessed, e.g. **Equalizer**.

Overview of Burmester® surround sound system

Function	Options
Equalizer	Sets treble, mid-range and base
Balance/fader	Moves the sound focus: left/right and front/rear
Surround	Optimizes sound playback for all seats

Setting treble, mid-range and bass



- ▶ Call up the sound menu (▷ page 131).
- ▶ Turn the controller until **Equalizer** is in the center.
- ▶ Slide  the controller.
The rotary menus for treble, mid-range and bass are activated.
- ▶ To switch between the rotary menus: slide  or  the controller.
- ▶ To make the desired **Equalizer** settings: turn the controller.
The rotary menus show the set values.
- ▶ To return to the menu: slide  the controller.
- ▶ To return to the basic menu: press the  button briefly.

Adjusting the balance/fader




Balance moves the focus of the sound between left and right.

Fader moves the focus of the sound between front and rear.

- ▶ Call up the sound menu (▷ page 131).
- ▶ Turn the controller until **Balance/Fader** is brought to the front and then slide $\odot \downarrow$ the controller.
- ▶ To activate the menu for balance and fader: press the controller.
- ▶ To adjust the balance focus: slide $\leftarrow \odot$ or $\odot \rightarrow$ the controller.
- ▶ To adjust the fader focus: slide $\odot \downarrow$ or $\uparrow \odot$ the controller.
An image shows the sound focus set.
- ▶ To exit the menu: press the $\leftarrow \square$ button.

- ▶ Call up the sound menu (▷ page 131).
- ▶ Turn the controller until **Surround** is in the center.
- ▶ Slide $\odot \downarrow$ the controller.
The left-hand rotary menu to switch surround sound on and off is activated.
- ▶ To activate **Surround**: turn the controller until **On** is active.
- ▶ To adjust the surround sound for **Front**, **Rear** or **All Seats**: slide $\odot \rightarrow$ the controller.
The right-hand rotary menu is activated.
- ▶ To set the desired **Surround** focus: turn the controller.
The menu symbol, text and image show the selected setting.
- ▶ To exit the menu: press the $\leftarrow \square$ button.

Setting surround sound



The **Surround** setting optimizes the sound playback for the selected seat position.